



**The ATM Forum**  
**Technical Committee**

**Network Call Correlation**  
**Identifier v1.0**

**AF-CS-0140.000**

**March, 2000**

© 2000 by The ATM Forum. This specification/document may be reproduced and distributed in whole, but (except as provided in the next sentence) not in part, for internal and informational use only and not for commercial distribution. Notwithstanding the foregoing sentence, any protocol implementation conformance statements (PICS) or implementation conformance statements (ICS) contained in this specification/document may be separately reproduced and distributed provided that it is reproduced and distributed in whole, but not in part, for uses other than commercial distribution. All other rights reserved. Except as expressly stated in this notice, no part of this specification/document may be reproduced or transmitted in any form or by any means, or stored in any information storage and retrieval system, without the prior written permission of The ATM Forum.

The information in this publication is believed to be accurate as of its publication date. Such information is subject to change without notice and The ATM Forum is not responsible for any errors. The ATM Forum does not assume any responsibility to update or correct any information in this publication. Notwithstanding anything to the contrary, neither The ATM Forum nor the publisher make any representation or warranty, expressed or implied, concerning the completeness, accuracy, or applicability of any information contained in this publication. No liability of any kind shall be assumed by The ATM Forum or the publisher as a result of reliance upon any information contained in this publication.

The receipt or any use of this document or its contents does not in any way create by implication or otherwise:

- Any express or implied license or right to or under any ATM Forum member company's patent, copyright, trademark or trade secret rights which are or may be associated with the ideas, techniques, concepts or expressions contained herein; nor
- Any warranty or representation that any ATM Forum member companies will announce any product(s) and/or service(s) related thereto, or if such announcements are made, that such announced product(s) and/or service(s) embody any or all of the ideas, technologies, or concepts contained herein; nor
- Any form of relationship between any ATM Forum member companies and the recipient or user of this document.

Implementation or use of specific ATM standards or recommendations and ATM Forum specifications will be voluntary, and no company shall agree or be obliged to implement them by virtue of participation in The ATM Forum.

The ATM Forum is a non-profit international organization accelerating industry cooperation on ATM technology. The ATM Forum does not, expressly or otherwise, endorse or promote any specific products or services.

NOTE: The user's attention is called to the possibility that implementation of the ATM interoperability specification contained herein may require use of an invention covered by patent rights held by ATM Forum Member companies or others. By publication of this ATM interoperability specification, no position is taken by The ATM Forum with respect to validity of any patent claims or of any patent rights related thereto or the ability to obtain the license to use such rights. ATM Forum Member companies agree to grant licenses under the relevant patents they own on reasonable and nondiscriminatory terms and conditions to applicants desiring to obtain such a license. For additional information contact:

The ATM Forum  
Worldwide Headquarters  
2570 West El Camino Real, Suite 304  
Mountain View, CA 94040-1313  
Tel: +1-650-949-6700  
Fax: +1-650-949-6705

## Acknowledgments

The Control and Signaling working group was chaired by Malcolm Wiles and his successor Gert Oster. Laurent Freléchoux was the editor for the *Network Call Correlation Identifier v1.0 addendum to PNNI v1.0 and AINI* specification. Tricci So was the editor for the *Addendum to UNI Signalling 4.0 for Network Call Correlation Identifier* specification. The minutes at related working group meetings were recorded by Gert Oster and his successor Thomas Cornély.

The following people made significant technical contributions to the *Network Call Correlation Identifier v1.0* specification:

Thomas Cornély

Robert Dianda

Laurent Freléchoux

Shawn McAllister

Gert Oster

Tricci So

Mickey Spiegel

Malcolm Wiles

## Table of contents

<b>1. GENERAL INFORMATION .....</b>	<b>8</b>
1.1 SCOPE.....	8
1.2 OVERVIEW.....	9
1.2.1 Network view.....	9
1.2.2 Nodal view.....	9
1.2.3 Modeling Considerations.....	9
<b>2. NETWORK CALL CORRELATION IDENTIFIER INFORMATION ELEMENT CODING .....</b>	<b>11</b>
<b>3. NCCI FEATURE FOR PNNI .....</b>	<b>13</b>
3.1 ADDITIONS TO PNNI SIGNALING MESSAGES.....	13
3.1.1 SETUP.....	13
3.1.2 ADD PARTY.....	13
3.1.3 CO-BI SETUP.....	13
3.2 NCCI PROCEDURES FOR PNNI.....	14
3.2.1 Procedures for Point-to-Point calls.....	14
3.2.2 Procedures for Point-to-Multipoint calls.....	14
3.2.3 NCCI information element content validation.....	15
3.2.4 Storing the NCCI.....	15
<b>4. NCCI FEATURE FOR AINI .....</b>	<b>15</b>
4.1 ADDITIONS TO AINI SIGNALING MESSAGES.....	15
4.1.1 CONNECT.....	15
4.1.2 CO-BI SETUP.....	15
4.2 NCCI PROCEDURES FOR AINI.....	15
4.2.1 Procedures for Point-to-Point calls.....	15
4.2.2 Procedures for Point-to-Multipoint calls.....	16
4.2.3 Storing the NCCI.....	17
4.2.4 Interworking between AINI and B-ISUP.....	17
<b>5. NCCI FEATURE FOR UNI.....</b>	<b>18</b>
5.1 ADDITIONS TO UNI SIGNALING MESSAGES.....	18
5.1.1 SETUP.....	19
5.1.2 ADD PARTY.....	19
5.1.3 CONNECT.....	19
5.2 NCCI PROCEDURES FOR UNI.....	19
5.2.1 Procedures for Point-to-point calls.....	19
5.2.2 Procedures for Point-to-Multipoint calls.....	20
5.2.3 Storing the NCCI.....	21
<b>6. INTERACTION WITH EXISTING FEATURES .....</b>	<b>21</b>
6.1 INTERACTION WITH SOFT PVCs.....	21
<b>7. COMPATIBILITY WITH NODES NOT SUPPORTING THIS FEATURE.....</b>	<b>21</b>
<b>8. REFERENCES.....</b>	<b>21</b>
<b>ANNEX A. NCCI SNMP MIB.....</b>	<b>22</b>
<b>ANNEX B. NCCI PICS PROFORMA FOR PNNI V1.0 .....</b>	<b>35</b>
B.1 INTRODUCTION.....	35
B.1.1 Scope.....	35
B.1.2 Normative References.....	35
B.1.3 Definitions.....	35

- B.1.4 Acronyms..... 35
- B.1.5 Conformance..... 36
- B.2 IDENTIFICATION OF THE IMPLEMENTATION ..... 37
- B.3 PICS PROFORMA..... 39
  - B.3.1 Global statement of conformance ..... 39
  - B.3.2 Instructions for Completing the PICS Proforma..... 39
- B.4 ROLES ..... 40
- B.5 NCCI ENCODING..... 40
- B.6 NCCI CAPABILITIES FOR POINT-TO-POINT CALLS ..... 40
- B.7 NCCI PROCEDURES FOR POINT-TO-POINT CALLS..... 41
- B.8 NCCI CAPABILITIES FOR POINT-TO-MULTIPOINT CALLS ..... 42
- B.9 NCCI PROCEDURES FOR POINT-TO-MULTIPOINT CALLS ..... 42
- ANNEX C. NCCI PICS PROFORMA FOR AINI V1.0 ..... 44**
  - C.1 INTRODUCTION..... 44
    - C.1.1 Scope..... 44
    - C.1.2 Normative References ..... 44
    - C.1.3 Definitions..... 44
    - C.1.4 Acronyms..... 44
    - C.1.5 Conformance..... 45
  - C.2 IDENTIFICATION OF THE IMPLEMENTATION ..... 46
  - C.3 PICS PROFORMA..... 48
    - C.3.1 Global statement of conformance ..... 48
    - C.3.2 Instructions for Completing the PICS Proforma..... 48
  - C.4 ROLES ..... 49
  - C.5 NCCI ENCODING..... 49
  - C.6 NCCI CAPABILITIES FOR POINT-TO-POINT CALLS ..... 49
  - C.7 NCCI PROCEDURES FOR POINT-TO-POINT CALLS..... 50
  - C.8 NCCI CAPABILITIES FOR POINT-TO-MULTIPOINT CALLS ..... 52
  - C.9 NCCI PROCEDURES FOR POINT-TO-MULTIPOINT CALLS ..... 53
- ANNEX D. NCCI PICS PROFORMA FOR UNI V4.0..... 55**
  - D.1 INTRODUCTION..... 55
    - D.1.1 Scope..... 55
    - D.1.2 Normative References ..... 55
    - D.1.3 Definitions..... 55
    - D.1.4 Acronyms..... 55
    - D.1.5 Conformance..... 56
  - D.2 IDENTIFICATION OF THE IMPLEMENTATION ..... 57
  - D.3 PICS PROFORMA..... 59
    - D.3.1 Global statement of conformance ..... 59
    - D.3.2 Instructions for Completing the PICS Proforma..... 59
  - D.4 ROLES ..... 60
  - D.5 NCCI ENCODING..... 60
  - D.6 NCCI CAPABILITIES FOR POINT-TO-POINT CALLS AT THE USER SIDE ..... 61
  - D.7 NCCI PROCEDURES FOR POINT-TO-POINT CALLS AT THE USER SIDE ..... 62
  - D.8 NCCI CAPABILITIES FOR POINT-TO-MULTIPOINT CALLS AT THE USER SIDE ..... 63
  - D.9 NCCI PROCEDURES FOR POINT-TO-MULTIPOINT CALLS AT THE USER SIDE..... 64
  - D.10 NCCI CAPABILITIES FOR POINT-TO-POINT CALLS AT THE NETWORK SIDE ..... 65
  - D.11 NCCI PROCEDURES FOR POINT-TO-POINT CALLS AT THE NETWORK SIDE ..... 66
  - D.12 NCCI CAPABILITIES FOR POINT-TO-MULTIPOINT CALLS AT THE NETWORK SIDE ..... 68
  - D.13 NCCI PROCEDURES FOR POINT-TO-MULTIPOINT CALLS AT THE NETWORK SIDE ..... 69
- APPENDIX A. B-ISUP NCCI FORMAT ..... 71**
- APPENDIX B. EXAMPLE OF NCCIS CORRELATION BETWEEN PRIVATE AND ATM SERVICE PROVIDER NETWORKS..... 71**

### Table of figures/tables

Figure 1-1 Primitives used in the NCCI procedures .....	10
Figure 2-1 Network call correlation identifier information element .....	11
Figure 2-2 Format of a AESA-based Network Call Correlation Identifier (28 octets).....	12
Table 3-1 Additional information element used in PNNI.....	13
Figure 3-1 Additional SETUP message content .....	13
Figure 3-2 Additional ADD PARTY message content .....	13
Figure 3-3 Additional CO-BI SETUP message content .....	14
Figure 4-1 Additional CONNECT message content .....	15
Table 4-1 Additional SETUP to IAM mapping.....	17
Table 4-2 Additional IAM to SETUP mapping.....	18
Table 4-3 Additional ADD PARTY to IAM mapping .....	18
Table 4-4 Additional IAM to ADD PARTY mapping .....	18
Table 4-5 Additional CONNECT to ANM mapping.....	18
Table 5-1: Additional Information Element for UNI Signalling 4.0 .....	19
Table 5-2: Additional Information Element for UNI SETUP message .....	19
Table 5-3: Additional Information Element for UNI ADD PARTY message .....	19
Table 5-4: Additional Information Element for UNI CONNECT message .....	19
Figure A-1 Format of a B-ISUP Network Call Correlation Identifier (9 octets).....	71
Figure B-1 Example of the networks interconnection when transporting NCCIs .....	72

This Addendum to ATM Forum PNNI v1.0 “Private Network-Network Interface Specification Version 1.0” [1], to ATM Forum “PNNI v1.0 Errata and PICS” [2], to ATM Forum “ATM Inter-Network Interface (AINI) Specifications” [3], and to ATM Forum “ATM User-Network Interface (UNI) Signalling Specification Version 4.0” [4] contains the description and specification of the network call correlation identifier for PNNI, AINI and UNI interfaces.

Section one contains information about the purpose of this addendum and its scope. Section two specifies the NCCI encoding and formats. Section three specifies the NCCI for PNNI interfaces, section four specifies the NCCI for AINI interfaces, while section five specifies the NCCI for UNI interfaces. Section six discusses the interactions with existing features, section seven the compatibility with nodes that do not support this feature and section eight contains the references to other documents. Annex A contains the NCCI SNMP MIB. Annex B contains the NCCI PICS Proforma for PNNI, Annex C contains the NCCI PICS Proforma for AINI and Annex D contains the NCCI PICS Proforma for UNI. Appendix A contains an informative description of the B-ISUP NCCI. Appendix B contains an informative example of NCCIs correlation between private and ATM Service Provider networks.

## 1. General information

The purpose of the Network call correlation identifier (NCCI) is to uniquely identify a call within a network. Currently only one connection can exist per call, therefore the NCCI can also be used to identify the connection associated with a call. Once a NCCI has been associated with a call it can be used by network management applications that need to refer to a specific call or to correlate different management records generated for the call. A NCCI can be associated with a virtual channel connection (SVCC, soft PVCC) or a virtual path connection (SVPC, soft PVPC). A NCCI can be associated with a point-to-point call or a point-to-multipoint call.

It is possible that a unique NCCI could appear to be non-unique for point-to-multipoint calls. It is possible for a point-to-multipoint call to enter a network node on multiple branches. Thus it would appear to be multiple calls to this node with the same NCCI. This also applies on a network basis if a network reuses the NCCI assigned by a previous network for point-to-multipoint calls. E.g. Branches of a point-to-multipoint call may enter a network at multiple interfaces.

### 1.1 Scope

#### [Normative]

The scope of this document is to specify signaling for the support of NCCI across PNNI interfaces, across AINI interfaces, and across private and public UNI interfaces.

Signaling as specified in this addendum provides for the association of a NCCI with a call. The decision of whether to assign a NCCI to a call, the process by which applications become aware of the NCCIs associated with calls, or in general the way NCCIs are used by applications are outside the scope of this document.

NCCI is an optional feature of PNNI v1.0 [1,2], of AINI v1.0 [3] and of UNI v4.0 [4].

This document does not address the NCCI procedures at an inter-network PNNI nor the interactions of the NCCI with Leaf Initiated Join at UNI v4.0.

A switch supporting the NCCI feature shall implement both the procedures for Point-to-Point calls and the procedures for Point-to-Multipoint calls. A switch shall support the association of a NCCI with calls for a virtual channel connection (SVCC, soft PVCC) and calls for a virtual path connection (SVPC, soft PVPC).

A device supporting PNNI, UNI or AINI shall be capable of forwarding a NCCI. A device supporting UNI or AINI shall also be capable of assigning a new NCCI, of discarding a NCCI and of returning a NCCI in a CONNECT message.

## 1.2 Overview

### [Informative]

#### 1.2.1 Network view

The NCCI capability allows a network to have an identifier for a call that can be used to correlate information gathered by any of the nodes in the path of the call. When the call enters a network (i.e. either at a UNI or at an AINI interface), the network may:

- If there is a NCCI included in the incoming call, forward the incoming NCCI, discard the incoming NCCI, or assign its own NCCI for the call.
- If there is no NCCI included in the incoming call, assign its own NCCI for the call.
- If a NCCI was assigned by this network, the NCCI may be included when a CONNECT message is sent in response to the originating user or the preceding network.

When the call exits a network (i.e. either at a UNI or at an AINI interface), the network may include a NCCI if one was assigned. If no NCCI was assigned, the network may assign one.

#### 1.2.2 Nodal view

When a call enters a node over either a UNI or an AINI interface, the node may:

- If there is a NCCI included in the incoming call, forward the incoming NCCI, discard the incoming NCCI, or assign its own NCCI for the call.
- If there is no NCCI included in the incoming call, assign its own NCCI for the call.
- If a NCCI was assigned by this node the NCCI may be included when a CONNECT message is sent in response to the originating user or the preceding network.

When the call exits a node over either a UNI or an AINI interface, the node may include a NCCI if one was assigned. If none was assigned, it may assign one.

At an intra-network interface, a node will transport the NCCI, if present, without modification.

#### 1.2.3 Modeling Considerations

This specification uses the same model as the procedures in the PNNI v1.0 and AINI specifications. This model is described in section 6.1 of the PNNIv1.0 specification and defines the "preceding" and "succeeding" sides of an interface.


In addition, this specification introduces the use of "primitives" exchanged between a *Call Control* entity and a *Protocol Control* entity. Figure 1-1 illustrates their use.

- The reception of a signaling message over an interface triggers the sending of a corresponding "indication" primitive to the Call Control entity.

- The reception of a "request" primitive from the Call Control entity triggers the sending of the corresponding signaling message over the interface.

The NCCI procedures deal with the assignment, forwarding or discarding of an NCCI. While these operations are logically associated with a "node", the model used in PNNI and AINI does not allow it. **For modeling purposes**, it is considered in the procedures sections that assignment of an NCCI typically occurs at the succeeding side of an interface.

The model used in this document, while necessary for the NCCI procedures specification, should not be considered as an additional constraint on possible implementations of the NCCI feature.



**Figure 1-1 Primitives used in the NCCI procedures**

## 2. Network call correlation identifier information element coding

The purpose of the Network call correlation identifier information element is to uniquely identify a call.

Bits								Octet
8	7	6	5	4	3	2	1	
Network call correlation identifier information element								
1	1	1	0	1	1	1	1	1
1 Ext	Coding standard		IE Instruction Field					2
Length of Network call correlation identifier information element contents								3
Length of Network call correlation identifier information contents (continued)								4
Identifier type								5
Identifier Length								5.1
Identifier Value								5.2 To 5.n

Figure 2-1 Network call correlation identifier information element

### Coding standard (octet 2)

Bits								Meaning
8	7	6	5	4	3	2	1	
1	1							ATM Forum specific

### Identifier Type (octet 5) & Identifier Length (octet 5.1)

The identifier type identifies the format of NCCI that is contained in the information element.

The following identifier types are defined:

Bits								Meaning
8	7	6	5	4	3	2	1	
0	0	0	0	0	0	0	1	AESA-based NCCI <i>Note 1</i>
0	0	0	0	0	0	1	0	B-ISUP NCCI <i>Note 2</i>

*Note 1* - The AESA-based NCCI is encoded according to the format shown in Figure 2-2. The identifier length shall be set to the value of 28 octets.

*Note 2* - The B-ISUP NCCI is encoded according to the format specified in 3.2.3.1 of ITU-T Recommendation Q.2726.3 [5]. The identifier length shall be set to the value of 9 octets.

### **Network call correlation identifier value (octets 5.2-5.n)**


To support interworking between B-ISUP and PNNI networks, two formats of NCCI are defined:

#### **a) AESA-based NCCI format**

As shown in Figure 2-2 the AESA-based NCCI format consists of a string of 28 octets divided in two parts:

**NCCI Root** The NCCI root (20 octets) consists of the full ATM End System Address (AESA) associated with the entity (e.g. node, interface) at which the NCCI is assigned to the call.

**NCCI Index** The NCCI index (8 octets) is locally unique within the context of the NCCI root. The semantics of this field are determined by the assigning entity. The values chosen shall be such as to guarantee a unique NCCI over a sufficiently long period of time. The assigning entity should sequence through a broad range of NCCI index values before reusing an index value. The assigning entity shall not immediately reuse a NCCI index value for another call.



**Figure 2-2 Format of a AESA-based Network Call Correlation Identifier (28 octets)**

#### **b) B-ISUP NCCI Format**

The B-ISUP NCCI format is specified in 3.2.3.1 of ITU-T Recommendation Q.2726.3 [5]. Appendix A contains an informative description of the B-ISUP NCCI.

### 3. NCCI feature for PNNI

#### 3.1 Additions to PNNI signaling messages

To provide the NCCI extension, the following information element is added to table 6-5 in 6.4.5.1/PNNI v1.0:

**Table 3-1 Additional information element used in PNNI**

Bits	Information Element	Max Length	Max no. of Occurrences
8 7 6 5 4 3 2 1			
1 1 1 0 1 1 1 1	Network call correlation identifier	38	1

#### 3.1.1 SETUP

The following information element is added to figure 6-8 in 6.3.1.6/PNNI v1.0:

Information Element	Reference	Type	Length
Network Call Correlation Identifier	2	O	15-38

**Figure 3-1 Additional SETUP message content**

#### 3.1.2 ADD PARTY

The following information element is added to figure 6-19 in 6.3.4.1/PNNI v1.0:

Information Element	Reference	Type	Length
Network Call Correlation Identifier	2	O	15-38

**Figure 3-2 Additional ADD PARTY message content**

#### 3.1.3 CO-BI SETUP

The following information element is added to table 26-2 in 26.8.1.2.3/GSS v1.0:

Information Element	Reference	Type	Length
Network Call Correlation Identifier	2	O	15-38

**Figure 3-3 Additional CO-BI SETUP message content**

## **3.2 NCCI Procedures for PNNI**

In this section, the term SETUP message refers to both the CO-BI SETUP message defined in GSS v1.0 and the SETUP message defined in PNNI v1.0.

### **3.2.1 Procedures for Point-to-Point calls**

*The following text is added to section 6.5.2.1/PNNI v1.0:*

When the preceding side of a PNNI receives a setup request, which does contain a NCCI, the node shall forward the NCCI information element. When the preceding side receives a setup request, which does not contain a NCCI, the node shall not assign a NCCI.

If the succeeding side of a PNNI receives a SETUP message containing a NCCI information element, the node shall forward the NCCI to the next interface. When the succeeding side receives a SETUP message, which does not contain a NCCI, the node shall not assign a NCCI.

### **3.2.2 Procedures for Point-to-Multipoint calls**

#### **3.2.2.1 Setup of the initial party**

The procedures for the setup of the initial party of a Point-to-Multipoint call are specified in section 6.6.1/PNNI v1.0. These procedures build upon the procedures in section 6.5/PNNI v1.0 as modified by section 3.2.1 which includes the NCCI specific procedures.

Additional procedures at the preceding side of the PNNI:

If an add party request contains an NCCI and is to be converted into a SETUP message, the procedures in section 3.2.1 shall apply, as if the NCCI was contained in a received setup request.

#### **3.2.2.2 Adding a party**

*The following text is added to section 6.6.2/PNNI v1.0:*

At the preceding side of the PNNI:

If a received add party request contains a NCCI, the node shall forward the NCCI as it received it. If a received add party request does not contain a NCCI, the node shall not assign a NCCI

At the succeeding side of the PNNI:

If a received ADD PARTY message contains a NCCI information element, the node shall forward the NCCI as it received it to the preceding side of the next interface. If a received ADD PARTY message does not contain a NCCI information element, the node shall not assign a NCCI.

### **3.2.3 NCCI information element content validation**

If a NCCI information element is received in a valid message, no content validation shall be performed on the NCCI information element, other than verifying the maximum information element length. If the call is progressed, the received NCCI information element shall be forwarded without modification, provided that the next interface is a PNNI interface. This allows support for other NCCI types in the future.

### 3.2.4 Storing the NCCI

A node may store the NCCI associated with a call (e.g. for recording call related information).

## 4. NCCI feature for AINI

### 4.1 Additions to AINI signaling messages

Section 3.1 of this document applies to AINI unless explicitly described in this section.

#### 4.1.1 CONNECT

*The following information element is added to figure 6-5 in 6.3.1.3/PNNI v1.0:*

Information Element	Reference	Type	Length
Network Call Correlation Identifier	2	O	15-38

**Figure 4-1 Additional CONNECT message content**

#### 4.1.2 CO-BI SETUP

Section 3.1.3 is not supported.

### 4.2 NCCI Procedures for AINI

#### 4.2.1 Procedures for Point-to-Point calls

*The following text is added to section 6.5.2.1/PNNI v1.0*

When the preceding side of the AINI receives a setup request containing a NCCI, the node may forward the NCCI, may discard the NCCI, but shall not assign a NCCI.

If the preceding side of the AINI receives a setup request not containing a NCCI, the node may assign a NCCI to the call.

When the succeeding side of the AINI receives a SETUP message containing a NCCI information element, the node may forward the NCCI, may discard the NCCI, or may assign a new NCCI to the call.

If the succeeding side of the AINI receives a SETUP message not containing a NCCI information element, the node may assign a NCCI to the call.

When a NCCI is assigned, the following shall apply:

- The NCCI shall be coded in a NCCI information element, as described in section 2.
- The NCCI information element shall be added to the SETUP message/setup indication.

The node shall guarantee a unique NCCI value for all calls that are assigned a NCCI at that location over a sufficiently long period of time.

The following procedures apply at the succeeding side of the AINI:

- If a NCCI was assigned during the setup phase, the node may insert the NCCI in the CONNECT message prior to progressing the message towards the preceding side.
- A NCCI included in the CONNECT message must be the one assigned by this node.
- If the node at the succeeding side of the AINI did not assign a NCCI, no NCCI shall be returned in the CONNECT message.

When a NCCI is returned in a CONNECT message, the following shall apply:

- The NCCI shall be coded in a NCCI information element, as described in section 2.
- The IE instruction field shall be coded with the pass along request bit set to 0.

When a NCCI information element is received in a CONNECT message, the NCCI may be stored and the NCCI information element is discarded before the message is forwarded towards the calling party.

## **4.2.2 Procedures for Point-to-Multipoint calls**

### **4.2.2.1 Setup of the initial party**

The procedures for the setup of the initial party of a Point-to-Multipoint call are specified in section 6.6.1/PNNI v1.0. These procedures build upon the procedures in section 6.5/PNNI v1.0 as modified by section 4.2.1 which includes the NCCI specific procedures.

Additional procedures at the preceding side of the AINI:

If an add party request is to be converted into a SETUP message, the procedures in section 4.2.1 shall apply, as if a setup request was received.

#### **4.2.2.2 Adding a party**

*The following text is added to section 6.6.2/AINI v1.0:*

At the preceding side of the AINI:

If a NCCI value was assigned to a point-to-multipoint call at the preceding side by the node, all ADD PARTY messages sent for this call over this interface shall contain the same NCCI information element.

If a received add party request contains a NCCI, and if the initial setup request contained a NCCI which has been forwarded, the node shall forward the NCCI information element as it received it.

If the initial SETUP message did not contain a NCCI information element, the node shall not include any NCCI information element in subsequent ADD PARTY messages.

At the succeeding side of the AINI:

If a NCCI value was assigned to a point-to-multipoint call at the succeeding side by this node, all add party indications sent for this call shall contain the same NCCI.

If a received ADD PARTY message contains a NCCI information element, and if the initial SETUP message contained a NCCI information element which has been forwarded to the preceding side of the next interface, the node shall forward the NCCI as it received it.

If the initial setup indication did not contain a NCCI, the node shall not include any NCCI in subsequent add party indications.

### 4.2.3 Storing the NCCI

A node shall store the NCCI associated with a call when the call is a Point-to-Multipoint connection and the node has assigned the NCCI. Otherwise, a node may store the NCCI (e.g. for recording call related information).

### 4.2.4 Interworking between AINI and B-ISUP

The following row is added to the table of AINI/4.1.1.2.1.1:

AINI to B-ISUP	
SETUP	IAM
Network Call Correlation Identifier	Network Call Correlation Identifier (Note 1)

Note 1 - Interworking with B-ISUP is only possible if the Network Call Correlation Identifier has a B-ISUP format. If the NCCI in the NCCI information element has any other format, the information element shall be dropped. Networks with BISUP interfaces should only use the BISUP format of NCCI and thus avoid an interworking problem between AINI and BISUP.

**Table 4-1 Additional SETUP to IAM mapping**

The following row is added to the table of AINI/4.1.1.2.1.2:

B-ISUP to AINI	
IAM	SETUP
Network Call Correlation Identifier	Network Call Correlation Identifier

**Table 4-2 Additional IAM to SETUP mapping**

The following row is added to the table of AINI/4.1.4.2.1.2:

AINI to B-ISUP	
ADD PARTY	IAM
Network Call Correlation Identifier	Network Call Correlation Identifier (Note 1)

Note 1 - Interworking with B-ISUP is only possible if the Network Call Correlation Identifier has a B-ISUP format. If the NCCI in the NCCI information element has any other format, the information element shall be dropped. Networks with BISUP interfaces should only use the BISUP format of NCCI and thus avoid an interworking problem between AINI and BISUP.

**Table 4-3 Additional ADD PARTY to IAM mapping**

The following row is added to the table of AINI/4.1.4.3.1.2:

B-ISUP to AINI	
IAM	ADD PARTY
Network Call Correlation Identifier	Network Call Correlation Identifier

**Table 4-4 Additional IAM to ADD PARTY mapping**

The following row is added to the table of AINI/4.1.1.2.4.1:

AINI to B-ISUP	
CONNECT	ANM
Network Call Correlation Identifier	Not carried

**Table 4-5 Additional CONNECT to ANM mapping**

## 5. NCCI feature for UNI

### 5.1 Additions to UNI signaling messages

To support a NCCI at the UNI, the following information element is added to Table2-1 of UNI Signalling Specification V4.0:

Bits	Information Element	Max. Length	Max. no. of Occurences
8 7 6 5 4 3 2 1	Network Call Correlation Identifier	38	1

**Table 5-1: Additional Information Element for UNI Signalling 4.0**

#### 5.1.1 SETUP

The following information element is added to Table 3-8/Q.2931:

Information Element	Reference	Direction	Type	Length
Network Call Correlation Identifier	2	both	O	15 - 38

**Table 5-2: Additional Information Element for UNI SETUP message**

#### 5.1.2 ADD PARTY

The following information element is added to Table 8-8/Q.2971:

Information Element	Reference	Direction	Type	Length
Network Call Correlation Identifier	2	both	O	15 - 38

**Table 5-3: Additional Information Element for UNI ADD PARTY message**

### 5.1.3 CONNECT

*The following information element is added to Table 3-4/Q.2931:*

Information Element	Reference	Direction	Type	Length
Network Call Correlation Identifier	2	both	O	15 - 38

**Table 5-4: Additional Information Element for UNI CONNECT message**

## 5.2 NCCI Procedures for UNI

The following procedures apply to all types of UNI interfaces.

### 5.2.1 Procedures for Point-to-point calls

#### 5.2.1.1 Call establishment at the originating interface

*The procedures of section 4.2.1 are added to section 5.1/Q.2931 with the following changes:*

Any occurrence of 'preceding' (respectively 'succeeding') is replaced by 'user' (respectively 'network'). Any occurrence of 'AINI' is replaced by 'UNI'. In the procedures for the user side, any occurrence of 'node' is replaced by 'user'.

The coding of the pass along request bit in the IE instruction field of the NCCI information element does not apply.

#### 5.2.1.2 Call establishment at the destination interface

*The procedures of section 4.2.1 are added to section 5.2/Q.2931 with the following modifications:*

Any occurrence of 'preceding' (respectively 'succeeding') is replaced by 'network' (respectively 'user'). Any occurrence of 'AINI' is replaced by 'UNI'. In the procedures for the user side, any occurrence of 'node' is replaced by 'user'.

The coding of the pass along request bit in the IE instruction field of the NCCI information element does not apply.

### 5.2.2 Procedures for Point-to-Multipoint calls

#### 5.2.2.1 Adding a party at the originating interface

##### 5.2.2.1.1 Setup of the first party

The procedures in section 5.0/UNI v4.0 as modified by section 5.2.1.1 shall apply, augmented by the following :

If an add party request is to be converted into a SETUP message, the procedures in section 5.2.1.1 shall apply, as if a setup request was received.

#### **5.2.2.1.2 Adding a PARTY**

*The procedures of section 4.2.2.2 are added to section 5.0/ UNI v4.0. with the following changes:*

Any occurrence of 'preceding' (respectively 'succeeding') is replaced by 'user' (respectively 'network'). Any occurrence of 'AINI' is replaced by 'UNI'. In the procedures for the user side, any occurrence of 'node' is replaced by 'user'.

The coding of the pass along request bit in the IE instruction field of the NCCI information element does not apply.

#### **5.2.2.2 Adding a party at the destination interface**

##### **5.2.2.2.1 Setup of the first party**

The procedures in section 5.0/UNI v4.0 as modified by section 5.2.1.2 shall apply, augmented by the following :

If an add party request is to be converted into a SETUP message, the procedures in section 5.2.1.2 shall apply, as if a setup request was received.

##### **5.2.2.2.2 Adding a PARTY**

*The procedures of section 4.2.2.2 are added to section 5.0/ UNI v4.0. with the following modifications:*

Any occurrence of 'preceding' (respectively 'succeeding') is replaced by 'network' (respectively 'user'). Any occurrence of 'AINI' is replaced by 'UNI'. In the procedures for the user side, any occurrence of 'node' is replaced by 'user'.

The coding of the pass along request bit in the IE instruction field of the NCCI information element does not apply.

#### **5.2.3 Storing the NCCI**

Section 4.2.3 applies.

### **6. Interaction with existing features**

#### **6.1 Interaction with Soft PVCs.**

When reestablishing a Soft PVCC or a Soft PVPC the same NCCI that was initially assigned shall be used.

### **7. Compatibility with nodes not supporting this feature**

To handle consistently NCCIs according to the procedures described in section 3, when coding the NCCI IE at a PNNI, the IE instruction field of the NCCI IE should be coded with the "pass along request" bit set to 1. Both the IE instruction field flag (bit 5) and the pass along request bit (bit 4) should be set to "1".

When coding the NCCI IE at a AINI, the IE instruction field of the NCCI IE should be coded with the IE instruction field flag (bit 5) set to “1” and the IE action indicator (bits 3-1) set to “Discard information element and proceed”. The pass along request bit (bit 4) should be set to “0”.

When coding the NCCI IE at a UNI, the IE instruction field of the NCCI IE should be coded with the IE instruction field flag (bit 5) set to “1” and the IE action indicator (bits 3-1) set to “Discard information element and proceed”.

## 8. References

- [1] *Private Network-Network Interface Specification Version 1.0*, ATM Forum af-pnni-0055.000, March 1996
- [2] *PNNI v1.0 Errata and PICS*, ATM Forum af-pnni-0081.000, May 1997
- [3] *ATM Inter-Network Interface (AINI) Specifications*, ATM Forum af-cs-0125.000, April 1999
- [4] *ATM User-Network Interface (UNI) Signalling Specification Version 4.0*, af-sig-0061.00, July 1996
- [5] *B-ISDN user part – Network generated session identifier*, ITU-T Recommendation Q.2726.3, June 1996
- [6] *PNNI 1.0 Addendum 1 - B-QSIG Interworking and Generic Support for Supplementary Services*, ATM Forum af-cs-0102.000, October 1998

## Annex A. NCCI SNMP MIB

NCCI-MIB DEFINITIONS ::= BEGIN

```
IMPORTS
    MODULE-IDENTITY, OBJECT-TYPE, enterprises
        FROM SNMPv2-SMI
    TEXTUAL-CONVENTION, RowStatus, TruthValue
        FROM SNMPv2-TC
    ifIndex
        FROM IF-MIB
    atmVclEntry, atmVplEntry
        FROM ATM-MIB
    MODULE-COMPLIANCE, OBJECT-GROUP
        FROM SNMPv2-CONF;

atmfNcciMIB MODULE-IDENTITY
    LAST-UPDATED      "0002290000Z"
    ORGANIZATION      "The ATM Forum"
    CONTACT-INFO
        "The ATM Forum
        2570 West El Camino Real, Suite 304
        Mountain View, CA 94040-1313 USA
        Phone: +1 415-949-6700
        Fax:    +1 415-949-6705
        info@atmforum.com"
    DESCRIPTION
        "The MIB module for managing the ATM Forum
        Network Call Correlation Identifier (NCCI) v1.0"
    REVISION "0002290000Z"
    DESCRIPTION
        "Initial version of the MIB module for managing the ATM Forum
        Network Call Correlation Identifier v1.0."
    ::= { atmfNcci 1 }

-- The object identifier subtree for the ATM Forum NCCI MIBs

atmForum          OBJECT IDENTIFIER ::= { enterprises 353 }
atmForumNetworkManagement OBJECT IDENTIFIER ::= { atmForum 5 }
atmfSignalling    OBJECT IDENTIFIER ::= { atmForumNetworkManagement 9 }
atmfNcci          OBJECT IDENTIFIER ::= { atmfSignalling 1 }

ncciMIBObjects OBJECT IDENTIFIER ::= { atmfNcciMIB 1 }

-- =====
-- atmNCCIType
-- =====

AtmNcciType ::= TEXTUAL-CONVENTION
    STATUS      current
    DESCRIPTION
        "The network call correlation identifier (NCCI) is used to
        uniquely identify a call over ATM networks.

        The associated call can be either a point-to-point or
        point-to-multipoint call. Both VCCs and VPCs can be
        associated with a network call correlation identifier.
        A network call correlation identifier (NCCI) can be coded
```

under two formats : The AESA-based format or the B-ISUP format


The AESA-based NCCI has a length of 28 bytes and is composed as follows :

- The NCCI root (20 octets) contains the AESA associated with the entity (node, interface) at which the NCCI is first assigned to that call.
- The NCCI index (8 octets) is used in combination with the AESA to provide a NCCI that is unique over a sufficiently long period of time.



The B-ISUP NCCI has a length of 9 bytes and is composed as follows (defined in ITU Recommendation Q.2726.3) :

- The network identifier (2 octets of 4 BCD digits) consists of a 0 followed by an E.164 country code followed by a sufficient number of 0s to make 4 digits.
- The point code (3 octets) contains the SS7 point code of the node where the NCCI is assigned.
- The Call identifier (4 octets) is used in combination with the Point Code and the Net ID to provide a NCCI that is unique over a long period of time.



"

REFERENCE

"ATM Forum NCCI v1.0 section 2"

```
SYNTAX          INTEGER {  
                    none (0),  
                    aesaBased(1),  
                    bisup(2)  
                    }
```

```
-- =====  
-- atmNCCI  
-- =====
```

AtmNcci ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"Describes the value of a NCCI

Two types of NCCI are defined: the AESA-based and the B-ISUP formats. These formats are explained in the AtmNcciType definition.

When the AtmNcciType is equal to none, it means that no NCCI is contained in the variable. The length of AtmNcci is equal to zero byte."

REFERENCE

"ATM Forum NCCI v1.0 section 2"

SYNTAX OCTET STRING (SIZE (0|9|28))

-- =====  
-- atmNCCIRoot  
-- =====

AtmNcciRoot ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"The root portion of a NCCI.

Two types of NCCI are defined: the AESA-based and the B-ISUP formats. These formats are explained in the atmNcciType definition.

For a NCCI in a AESA-based format, the root portion is equivalent to the NCCI Root as described in the atmNcciType definition (20 bytes).

For a NCCI in a B-ISUP format, the root portion is equivalent to the NCCI Network ID + Point Code as described in the atmNcciType definition (5 bytes).

When the AtmNcciType is equal to none, it means that no NCCI is contained in the variable. The length of AtmNcciRoot is equal to zero byte."

REFERENCE

"ATM Forum NCCI v1.0 section 2"

SYNTAX OCTET STRING (SIZE (0|5|20))

-- =====  
-- Per Interface NCCI Configuration  
-- =====

ncciIfTable OBJECT-TYPE

SYNTAX SEQUENCE OF NcciIfEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"The table used to manage the assignment of NCCIs on a per interface basis. One row of this table can be created by the managed system for each row in the ifTable of atm(37).

An entry in this table configures the management of NCCIs for SVCs, SVPs, soft PVCs, and soft PVPs. The configuration can be applied to point-to-point calls, point-to-multipoint calls or both.

When no entry in this table has been configured for a given interface and direction, the action is to forward the received NCCI if present, and not to assign any NCCI even when no NCCI is received."

REFERENCE

```
"ATM Forum NCCI v1.0"  
 ::= { ncciMIBObjects 1 }
```

ncciIfEntry OBJECT-TYPE

```
SYNTAX      NcciIfEntry  
MAX-ACCESS  not-accessible  
STATUS      current  
DESCRIPTION
```

"Each entry in this table is used to configure the NCCI operations for SETUP messages of svcs and svps.

The entry is also be used to configure the assignment of NCCIs to soft pvcs or soft pvps whose terminating legs are located on the interface indexed by ifIndex.

The actions configured in this entry are subject to the procedures described in sections 3,4 and 5 of the ATM Forum NCCI v1.0.

The ifIndex is used as the instance ID to uniquely identify the interface on the local switching system. This index has the same value as the ifIndex object defined in RFC 1573 for the same interface, since this table correlates with the ifTable in RFC 1573."

```
INDEX { ifIndex, ncciIfDirection }  
 ::= { ncciIfTable 1 }
```

NcciIfEntry ::=

```
SEQUENCE {  
    ncciIfDirection      INTEGER,  
    ncciIfAction         INTEGER,  
    ncciIfSave           BITS,  
    ncciIfinConnect     TruthValue,  
    ncciIfType           AtmNcciType,  
    ncciIfRoot           AtmNcciRoot,  
    ncciIfCastType       INTEGER,  
    ncciIfVpType         INTEGER,  
    ncciIfVcType         INTEGER,  
    ncciIfRowStatus      RowStatus  
}
```

ncciIfDirection OBJECT-TYPE

```
SYNTAX      INTEGER { incoming (1),  
                      outgoing (2)  
}
```

```
MAX-ACCESS  not-accessible  
STATUS      current
```

DESCRIPTION

"Indicates if the configuration applies to incoming setup indications or to outgoing setup requests."

```
 ::= { ncciIfEntry 1 }
```

ncciIfAction OBJECT-TYPE

```
SYNTAX      INTEGER {  
    discardNcci (1),  
    assignNcci (2),  
    forwardNcci (3)  
}
```

```
MAX-ACCESS  read-create
```

```
STATUS      current
```

DESCRIPTION

"Indicates what action to perform when a setup indication is received on this interface.

'discardNcci' means that if an incoming setup indication is received, if a NCCI is present in the setup, it is discarded and no NCCI is assigned to the call. The values contained in ncciIfType and ncciIfRoot are ignored.

'assignNcci' means that if an incoming setup indication is received, a new locally generated NCCI is assigned to the call. 'assignNcci' implies that the ncciIfType is set to a value different than 'none'.

'forwardNcci' means that if an incoming setup indication is received, if a NCCI is present in the setup, it is forwarded to the next interface.

If no NCCI is present:

- a locally generated NCCI is assigned to the call if the ncciIfType is set to a value different than 'none'.
- no locally generated NCCI is assigned to the call if the ncciIfType is set to the value 'none'."

REFERENCE

"ATM Forum NCCI v1.0 sections 3, 4, and 5"

```
DEFVAL { forwardNcci }  
::= { ncciIfEntry 2 }
```

ncciIfSave OBJECT-TYPE

```
SYNTAX      BITS { localNcci (0),  
                  remoteNcci (1)  
                }
```

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"Indicates whether NCCIs are saved for calls on this interface

'localNcci' indicates that the value of

- a newly assigned NCCI, or
  - a received NCCI if it has been forwarded, or
  - a received NCCI if it has been discarded and either the atmVclConnKind or the atmVplConnKind is 'svcOutgoing', or
  - a received NCCI if the atmVclConnKind or atmVplConnKind is 'spvcTarget'
- is stored.

'remoteNcci' indicates that the value of

- a NCCI received in the SETUP message if either the atmVclConnKind or the atmVplConnKind is 'svcIncoming', or
  - a NCCI received in the CONNECT message if either the atmVclConnKind or the atmVplConnKind is 'svcOutgoing'
- is stored."

```
::= { ncciIfEntry 3 }
```

ncciIfinConnect OBJECT-TYPE

```
SYNTAX      TruthValue
```

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"Indicates whether a locally generated NCCI assigned to an incoming call on this interface is returned in the CONNECT message.

'true' means that the NCCI is returned in the CONNECT message.

This object is only applicable on AINI or UNI interfaces and when ncciIfDirection has the value 'incoming'."

DEFVAL { true }  
::= { ncciIfEntry 4 }

ncciIfType OBJECT-TYPE

SYNTAX AtmNcciType  
MAX-ACCESS read-create  
STATUS current

DESCRIPTION

"Indicates the format of the NCCI to be assigned on the specified interface."

REFERENCE

"ATM Forum NCCI v1.0 section 2"

DEFVAL { none }  
::= { ncciIfEntry 5 }

ncciIfRoot OBJECT-TYPE

SYNTAX AtmNcciRoot  
MAX-ACCESS read-create  
STATUS current

DESCRIPTION

"Contains the NCCI Root or the NCCI Network ID + Point Code to be used by the switching system when generating a NCCI on the specified interface.

If the ncciIfRoot value is not supplied prior to creating the row, the switching system is in charge of deriving the ncciIfRoot value from one of the switch addresses.

The value of the NCCI root assigned by the switch can be read from this variable when the entry in the table has been activated.

The length of the NCCI must match the length of the specified NCCI format."

REFERENCE

"ATM Forum NCCI v1.0 section 2"

::= { ncciIfEntry 6 }

ncciIfCastType OBJECT-TYPE

SYNTAX INTEGER {  
    p2p (1),  
    p2mp (2),  
    p2pANDp2mp (3)  
}  
MAX-ACCESS read-create  
STATUS current

DESCRIPTION

"Indicates if the NCCI configuration for this interface applies to point-to-point calls only, to point-to-multipoint calls only, or to both"

::= { ncciIfEntry 7 }

ncciIfVpType OBJECT-TYPE

SYNTAX INTEGER {

```

                                none (1),
                                svp (2),
                                spvpInitiator (3),
                                svpANDspvpInitiator (4)
                                }
MAX-ACCESS      read-create
STATUS          current
DESCRIPTION
    "Indicates if the NCCI configuration for this interface
    applies to svps only, to soft pvps only, to both, or to none

    'svp' value applies to switched portions of a soft pvp as well
    as switched vps."
 ::= { ncciIfEntry 8}

ncciIfVcType OBJECT-TYPE
SYNTAX          INTEGER {
                                none (1),
                                svc (2),
                                spvcInitiator (3),
                                svcANDspvcInitiator (4)
                                }
MAX-ACCESS      read-create
STATUS          current
DESCRIPTION
    "Indicates if the NCCI configuration for this interface
    applies to svcs only, to soft pvcs only, to both, or to none
    'svc' value applies to switched portions of a soft pvc as well
    as switched vcs."
 ::= { ncciIfEntry 9}

ncciIfRowStatus OBJECT-TYPE
SYNTAX          RowStatus
MAX-ACCESS      read-create
STATUS          current
DESCRIPTION
    "To create, delete, activate and de-activate a NCCI
    configuration for an interface."
 ::= { ncciIfEntry 10}

-- =====
-- Ncci Vpl Table
-- =====

ncciVpTable OBJECT-TYPE
SYNTAX          SEQUENCE OF NcciVpEntry
MAX-ACCESS      not-accessible
STATUS          current
DESCRIPTION
    "The table used to manage NCCIs and their association
    with a point-to-point or point-to-multipoints PVPs and
    Soft PVPs in a switching system.

    This table is an augmentation of atmVplTable."
REFERENCE
    "ATM Forum NCCI v1.0"
 ::= { ncciMIBObjects 2 }

ncciVpEntry OBJECT-TYPE
SYNTAX          NcciVpEntry
MAX-ACCESS      not-accessible
STATUS          current
```

DESCRIPTION

"Each entry in this table represents a NCCI associated with a PVP or Soft PVP connection.

The content of this table reflects only the NCCI values associated with VPCs. atmVplTable is specified in ATM-MIB (RFC 2515).

This entry serves to identify the VPL on the interface."

AUGMENTS { atmVplEntry }  
 ::= { ncciVpTable 1 }

NcciVpEntry ::=

SEQUENCE {  
    ncciVpLocalType                AtmNcciType,  
    ncciVpLocalValue              AtmNcci,  
    ncciVpRemoteType              AtmNcciType,  
    ncciVpRemoteValue             AtmNcci  
}

ncciVpLocalType OBJECT-TYPE

SYNTAX          AtmNcciType  
MAX-ACCESS      read-only  
STATUS          current

DESCRIPTION

"The format of the NCCI contained in the NCCI ncciVpLocalValue."

REFERENCE

"ATM Forum NCCI v1.0 section 2"

::= { ncciVpEntry 1 }

ncciVpLocalValue OBJECT-TYPE

SYNTAX          AtmNcci  
MAX-ACCESS      read-only  
STATUS          current

DESCRIPTION

"The NCCI value associated with the VPC identified by its atmVpl. It contains the the value  
- of the assigned NCCI if a new NCCI has been assigned,  
- of a received NCCI if it has been forwarded,  
- of a received NCCI if it has been discarded and the atmVplConnKind for this entry is 'svcOutgoing'  
- of a received NCCI if the atmVplConnKind is 'spvcTarget'

The length and type of the NCCI is determined by the ncciVpLocalType."

REFERENCE

"ATM Forum NCCI v1.0 section 2"

::= { ncciVpEntry 2 }

ncciVpRemoteType OBJECT-TYPE

SYNTAX          AtmNcciType  
MAX-ACCESS      read-only  
STATUS          current

DESCRIPTION

"The format of the NCCI contained in the NCCI ncciVpRemoteValue."

REFERENCE

"ATM Forum NCCI v1.0 section 2"

::= { ncciVpEntry 3 }

```
ncciVpRemoteValue OBJECT-TYPE
    SYNTAX          AtmNcci
    MAX-ACCESS      read-only
    STATUS          current
    DESCRIPTION
        "The NCCI value associated with the VPC on the other side
        of the interface.

        When the atmVplConnKind for this entry is
        'svcIncoming', contains the NCCI value received in the SETUP
        message on the interface.

        When the atmVplConnKind for this entry is
        'svcOutgoing', contains the NCCI value
        received in the CONNECT message on the interface.

        The length and type of the NCCI is determined by the
        ncciVpRemoteType."
    REFERENCE
        "ATM Forum NCCI v1.0 section 2"
    ::= { ncciVpEntry 4 }
```

```
-- =====
-- Ncci Vcl Table
-- =====
```

```
ncciVcTable OBJECT-TYPE
    SYNTAX          SEQUENCE OF NcciVcEntry
    MAX-ACCESS      not-accessible
    STATUS          current
    DESCRIPTION
        "The table used to manage NCCIs and their association
        with a point-to-point or point-to-multipoints PVCs and
        Soft PVCs in a switching system.

        This table is an augmentation of atmVclTable."
    REFERENCE
        "ATM Forum NCCI v1.0"
    ::= { ncciMIBObjects 3 }
```

```
ncciVcEntry OBJECT-TYPE
    SYNTAX          NcciVcEntry
    MAX-ACCESS      not-accessible
    STATUS          current
    DESCRIPTION
        "Each entry in this table represents a NCCI associated with
        a PVC or Soft PVC connection.

        The content of this table reflects only the NCCI values
        associated with VCCs. atmVclTable is specified in
        ATM-MIB (RFC 2515).

        This entry serves to identify the VCL on the interface."
    AUGMENTS { atmVclEntry }
    ::= { ncciVcTable 1 }
```

```
NcciVcEntry ::=
    SEQUENCE {
        ncciVcLocalType      AtmNcciType,
        ncciVcLocalValue     AtmNcci,
        ncciVcRemoteType     AtmNcciType,
        ncciVcRemoteValue    AtmNcci
    }

ncciVcLocalType OBJECT-TYPE
    SYNTAX      AtmNcciType
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The format of the NCCI contained in the NCCI ncciVcLocalValue."
    REFERENCE
        "ATM Forum NCCI v1.0 section 2"
    ::= { ncciVcEntry 1 }

ncciVcLocalValue OBJECT-TYPE
    SYNTAX      AtmNcci
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The NCCI value associated with the VCC identified by
         its atmVcl. It contains the value
         - of the assigned NCCI if a new NCCI has been assigned,
         - of a received NCCI if it has been forwarded,
         - of a received NCCI if it has been discarded and the
           atmVclConnKind for this entry is 'svcOutgoing'
         - of a received NCCI if the atmVclConnKind is 'spvcTarget'

         The length and type of the NCCI is determined by the
         ncciVcLocalType."
    REFERENCE
        "ATM Forum NCCI v1.0 section 2"
    ::= { ncciVcEntry 2 }

ncciVcRemoteType OBJECT-TYPE
    SYNTAX      AtmNcciType
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The format of the NCCI contained in the NCCI ncciVcRemoteValue."
    REFERENCE
        "ATM Forum NCCI v1.0 section 2"
    ::= { ncciVcEntry 3 }

ncciVcRemoteValue OBJECT-TYPE
    SYNTAX      AtmNcci
    MAX-ACCESS  read-only
    STATUS      current
    DESCRIPTION
        "The NCCI value associated with the VCC on the other side
         of the interface.

         When the atmVclConnKind for this entry is
         'svcIncoming', contains the NCCI value received in the SETUP
```

message on the interface.

When the atmVclConnKind for this entry is  
'svcOutgoing', contains the NCCI value  
received in the CONNECT message on the interface.

The length and type of the NCCI is determined by the  
ncciVcRemoteType."

REFERENCE

"ATM Forum NCCI v1.0 section 2"  
::= { ncciVcEntry 4 }

-- conformance information

ncciMIBConformance

OBJECT IDENTIFIER ::= { atmfNcciMIB 2 }

ncciMIBCompliances

OBJECT IDENTIFIER ::= { ncciMIBConformance 1 }

ncciMIBGroups

OBJECT IDENTIFIER ::= { ncciMIBConformance 2 }

-- compliance statements

ncciMIBCompliance MODULE-COMPLIANCE

STATUS current

DESCRIPTION

"The compliance statement for entities which implement  
the AESA-based NCCI MIB.

Groups of the AESA-based NCCI objects required for using the  
NCCI extension are identified by the suffix MinGroup.

Groups of optional NCCI objects are identified by the  
suffix OptionalGroup."

MODULE -- this module

MANDATORY-GROUPS {  
ncciIfMinGroup,  
ncciVcMinGroup  
}

::= { ncciMIBCompliances 1 }

-- units of conformance

ncciIfMinGroup OBJECT-GROUP

OBJECTS {  
ncciIfAction,  
ncciIfSave,  
ncciIfinConnect,  
ncciIfType,  
ncciIfRoot,  
ncciIfCastType,  
ncciIfVcType,  
ncciIfRowStatus

```
    }
    STATUS current
    DESCRIPTION
        "A collection of per interface NCCI management objects required
        for managing the NCCI extension in a switching system."
    ::= { ncciMIBGroups 1 }

ncciVcMinGroup OBJECT-GROUP
    OBJECTS {
        ncciVcLocalType,
        ncciVcLocalValue,
        ncciVcRemoteType,
        ncciVcRemoteValue
    }
    STATUS current
    DESCRIPTION
        "A collection of per Vc NCCI objects required
        for managing the NCCI extension in a switching system."
    ::= { ncciMIBGroups 2 }

ncciIfVpOptionalGroup OBJECT-GROUP
    OBJECTS {
        ncciIfVpType
    }
    STATUS current
    DESCRIPTION
        "A collection of per interface NCCI management objects required
        for managing the NCCI extension when VPs are supported
        in this switching system."
    ::= { ncciMIBGroups 3 }

ncciVpOptionalGroup OBJECT-GROUP
    OBJECTS {
        ncciVpLocalType,
        ncciVpLocalValue,
        ncciVpRemoteType,
        ncciVpRemoteValue
    }
    STATUS current
    DESCRIPTION
        "A collection of per VP NCCI management objects required
        for managing the NCCI extension when VPs are supported
        in this switching system."
    ::= { ncciMIBGroups 4 }

END
```

## **Annex B. NCCI PICS Proforma for PNNI v1.0**

### **B.1 Introduction**

To evaluate conformance of a particular implementation, it is necessary to have a statement of which capabilities and options that have been implemented. Such a statement is called a Protocol Implementation Conformance Statement (PICS).

#### **B.1.1 Scope**

This document provides the PICS proforma for the Network Call Correlation Identifier v1.0 for PNNI v1.0, as specified in this document in compliance with the relevant requirements, and in accordance with the relevant guidelines, given in ISO/IEC 9646-2[2]. In most cases, statements contained in notes in the specification, which were intended as information, are not included in the PICS.

#### **B.1.2 Normative References**

- [1] ISO/IEC 9646-1:1994, Information technology - Open systems interconnection - Conformance testing methodology and framework - Part 1: General Concepts. (See also ITU Recommendation X.290(1995)).
- [2] ISO/IEC 9646-2:1994, Information technology - Open systems interconnection - Conformance testing methodology and interconnection - Part 2: Abstract test suite specification. (See also ITU Recommendation X.291(1995)).
- [3] Private Network-Network Interface Specification Version 1.0, ATM Forum af-pnni-0055.000, March 1996
- [4] PNNI v1.0 Errata and PICS, ATM Forum af-pnni-0081.000, May 1997

#### **B.1.3 Definitions**

This document uses the following terms defined in ISO/IEC 9646-1[1]:

- A Protocol Implementation Conformance Statement (PICS) is a statement made by the supplier of an implementation or system, stating which capabilities have been implemented for a given protocol.
- A PICS proforma is a document, in the form of a questionnaire, designed by the protocol specifier or conformance test suite specifier, which when completed for an implementation or system becomes the PICS.

#### **B.1.4 Acronyms**

IE	Information Element
IUT	Implementation Under Test
M	Mandatory requirements (these are to be observed in all cases)
O	Optional (may be selected to suit the implementation, provided that any requirements applicable to the options are observed)

NCCI Network Call Correlation Identifier

O.n Optional, but support is required for either at least one or only one of the options in the group labeled with the same numeral "n".

PICS Protocol Implementation Conformance Statement

### **B.1.5 Conformance**

The supplier of a protocol implementation which is claimed to conform to the ATM Forum Network Call Correlation Identifier v1.0 for PNNI v1.0 is required to complete a copy of the PICS proforma provided in this document and is required to provide the information necessary to identify both the supplier and the implementation.

## **B.2 Identification of the Implementation**

### **Implementation Under Test (IUT) Identification**

IUT Name: \_\_\_\_\_

IUT Version: \_\_\_\_\_

\_\_\_\_\_

### **System Under Test (SUT) Identification**

SUT Name: \_\_\_\_\_

Hardware Configuration: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Operating System: \_\_\_\_\_

### **Product Supplier**

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Telephone Number: \_\_\_\_\_

Facsimile Number: \_\_\_\_\_

Email Address: \_\_\_\_\_

Additional Information: \_\_\_\_\_

**Client**

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Telephone Number: \_\_\_\_\_

Facsimile Number: \_\_\_\_\_

Email Address: \_\_\_\_\_

Additional Information: \_\_\_\_\_

**PICS Contact Person**

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Telephone Number: \_\_\_\_\_

Facsimile Number: \_\_\_\_\_

Email Address: \_\_\_\_\_

Additional Information: \_\_\_\_\_

**PICS/System Conformance Statement**

Provide the relationship of the PICS with the System Conformance Statement for the system:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

**Identification of the protocol**

This PICS proforma applies to the following:

\* ATM Forum Network Call Correlation Identifier v1.0 for PNNI v1.0.

### **B.3 PICS Proforma**

#### **B.3.1 Global statement of conformance**

The implementation described in this PICS meets all of the mandatory requirements of the reference protocol.

YES

NO

Note: Answering "No" indicates non-conformance to the specified protocol. Non-supported mandatory capabilities are to be identified in the following tables, with an explanation by the implementor explaining why the implementation is non-conforming.

#### **B.3.2 Instructions for Completing the PICS Proforma**

The PICS Proforma is a fixed-format questionnaire. Answers to the questionnaire should be provided in the rightmost columns, either by simply indicating a restricted choice (such as Yes or No), or by entering a value or a set of range of values.

*A supplier may also provide additional information, categorized as exceptional or supplementary information. These additional information should be provided as items labeled X.<i> for exceptional information, or S.<i> for supplemental information, respectively, for cross reference purposes, where <i> is any unambiguous identification for the item. The exception and supplementary information are not mandatory and the PICS is complete without such information. The presence of optional supplementary or exception information should not affect test execution, and will in no way affect interoperability verification. The column labeled 'Reference' gives a pointer to sections of the protocol specification for which the PICS Proforma is being written.*

**B.4 Roles**

Item	Roles Does the IUT of the NCCI addendum to PNNI...	Status	Prerequisite	Reference	Support
NCCI-PP	The NCCI feature for Point-to-Point calls ?	M		1.1	[ ]Yes [ ]No
NCCI-PM	The NCCI feature for Point-to-Multipoint calls ?	M		1.1	[ ]Yes [ ]No
Comments:					

Table 1: Roles (PNNI)

**B.5 NCCI encoding**

Item	NCCI formats and encoding Is the IUT capable of...	Status	Prerequisite	Reference	Support
NCCI-E-1	Generating a NCCI information element as described in Figure 2-1?	M		2, 3.2.1,3.2.2	[ ]Yes [ ]No
NCCI-E-2	Generating a NCCI information element with the IE instruction field flag set to 1?	O		7	[ ]Yes [ ]No
NCCI-E-3	Generating a NCCI information element with the "pass along request" bit set to 1?	O		7	[ ]Yes [ ]No
NCCI-E-4	Including one NCCI information element in a SETUP message ?	M		3.1.1	[ ]Yes [ ]No
NCCI-E-5	Including one NCCI information element in an ADD PARTY message ?	M		3.1.2	[ ]Yes [ ]No
NCCI-E-6	Including one NCCI information element in a CO-BI SETUP message ?	M	MC 2.2/GSS	3.1.3	[ ]Yes [ ]No
NCCI-E-7	Including no more than one NCCI information elements in a SETUP message ?	M		3.1.1	[ ]Yes [ ]No
NCCI-E-8	Including no more than one NCCI information elements in an ADD PARTY message ?	M		3.1.2	[ ]Yes [ ]No
NCCI-E-9	Including no more than one NCCI information elements in a CO-BI SETUP message ?	M	MC 2.2/GSS	3.1.3	[ ]Yes [ ]No
Comments:					

Table 2: NCCI encoding (PNNI)

**B.6 NCCI capabilities for Point-to-Point calls**

Item	Capabilities for Point-to-Point calls Is the IUT capable of ...	Status	Prerequisite	Reference	Support
------	--	--------	--------------	-----------	---------

NCCI-PPC-1	At the succeeding side, receiving and processing a SETUP message for a Point-to-Point call containing a NCCI IE and forwarding the NCCI IE to the preceding side of the next interface as received ?	M		3.2.1	[ ]Yes [ ]No
NCCI-PPC-2	At the preceding side, receiving and processing a setup request for a Point-to-Point call containing a NCCI , and forwarding the NCCI IE to the succeeding node as received?	M		3.2.1	[ ]Yes [ ]No
Comments:					

Table 3: NCCI capabilities for Point-to-Point calls (PNNI)

### B.7 NCCI procedures for Point-to-Point calls

Item	Procedures for Point-to-Point calls Does the IUT ...	Status	Prerequisite	Reference	Support
NCCI-PPP-1	At the preceding side, forward the NCCI when receiving a setup request containing a NCCI?	M		3.2.1	[ ]Yes [ ]No
NCCI-PPP-2	At the preceding side, not assign a NCCI to the call when receiving a setup request not containing a NCCI?	M		3.2.1	[ ]Yes [ ]No
NCCI-PPP-3	At the succeeding side, forward the NCCI as received when receiving a SETUP message containing a NCCI information element?	M		3.2.1	[ ]Yes [ ]No
NCCI-PPP-4	At the succeeding side, not assign a NCCI to the call when receiving a SETUP message not containing a NCCI IE ?	M		3.2.1	[ ]Yes [ ]No
NCCI-PPP-5	When the next interface is a PNNI interface and a NCCI IE is received in a valid message, check only the maximum information element length of the NCCI IE and does not perform any other content validation on the IE ?	M		3.2.3	[ ]Yes [ ]No
NCCI-PPP-6	Support the same NCCI procedures for CO-BI SETUP message in the same way as the regular SETUP message?	M	MC 2.2/GSS	3.2	[ ] Yes [ ] No
Comments:					

Table 4: NCCI procedures for Point-to-Point calls (PNNI)

### B.8 NCCI capabilities for Point-to-Multipoint calls

Item	Capabilities for Point-to-Multipoint calls : Is the IUT capable of ...	Status	Prerequisite	Reference	Support
NCCI-PMC-1	At the preceding side, receiving and processing a setup request for a Point-to-Multipoint call containing a NCCI, and forwarding the NCCI IE to the succeeding node as received?	M		3.2.2.1	[ ]Yes [ ]No
NCCI-PMC-2	At the succeeding side, receiving and processing a SETUP message for a Point-to-Multipoint call containing a NCCI IE and forwarding the NCCI IE to the preceding side of the next interface as received ?	M		3.2.2.1	[ ]Yes [ ]No
NCCI-PMC-3	At the preceding side, receiving and processing an add party request for a Point-to-Multipoint call containing a NCCI, and forwarding the NCCI IE to the succeeding node as received?	M		3.2.2.2	[ ]Yes [ ]No
NCCI-PMC-4	At the succeeding side, receiving and processing an ADD PARTY message for a Point-to-Multipoint call containing a NCCI IE and forwarding the NCCI IE to the preceding side of the next interface as received ?	M		3.2.2.2	[ ]Yes [ ]No
Comments					

Table 5: NCCI capabilities for Point-to-Multipoint calls (PNNI)

### B.9 NCCI procedures for Point-to-Multipoint calls

Item	Procedures for Point-to-Multipoint calls : Does the IUT...	Status	Prerequisite	Reference	Support
NCCI-PMP-1	At the preceding side, forward the NCCI when receiving a setup request containing a NCCI?	M		3.2.2.1	[ ]Yes [ ]No
NCCI-PMP-2	At the preceding side, forward the NCCI when receiving an add party request containing a NCCI?	M		3.2.2.2	[ ]Yes [ ]No
NCCI-PMP-3	At the preceding side, not assign a NCCI to the call when receiving a setup request not containing a NCCI?	M		3.2.2.1	[ ]Yes [ ]No
NCCI-PMP-4	At the preceding side, not assign a NCCI to the call when receiving an add party request not containing a NCCI?	M		3.2.2.2	[ ]Yes [ ]No
NCCI-PMP-5	At the preceding side, include the unaltered NCCI received in an add party request into the SETUP message, when converting the add party request to a SETUP message ?	M		3.2.2.1	[ ]Yes [ ]No
NCCI-PMP-6	At the succeeding side, forward the NCCI information element as received when receiving a SETUP message containing a NCCI ?	M		3.2.2.1	[ ]Yes [ ]No

NCCI-PMP-7	At the succeeding side , forward the NCCI information element as received when receiving an ADD PARTY message containing a NCCI information element?	M		3.2.2.2	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PMP-8	At the succeeding side, not assign a NCCI to the call when receiving a SETUP message not containing a NCCI IE ?	M		3.2.2.1	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PMP-9	At the succeeding side, not assign a NCCI to the call when receiving an ADD PARTY message not containing a NCCI IE?	M		3.2.2.2	<input type="checkbox"/> Yes <input type="checkbox"/> No
Comments:					

Table 6: NCCI procedures for Point-to-Multipoint calls (PNNI)

## **Annex C. NCCI PICS Proforma for AINI v1.0**

### **C.1 Introduction**

To evaluate conformance of a particular implementation, it is necessary to have a statement of which capabilities and options that have been implemented. Such a statement is called a Protocol Implementation Conformance Statement (PICS).

#### **C.1.1 Scope**

This document provides the PICS proforma for the Network Call Correlation Identifier v1.0 for AINI v1.0, as specified in this document in compliance with the relevant requirements, and in accordance with the relevant guidelines, given in ISO/IEC 9646-2[2]. In most cases, statements contained in notes in the specification, which were intended as information, are not included in the PICS.

#### **C.1.2 Normative References**

- [1] ISO/IEC 9646-1:1994, Information technology - Open systems interconnection - Conformance testing methodology and framework - Part 1: General Concepts. (See also ITU Recommendation X.290(1995)).
- [2] ISO/IEC 9646-2:1994, Information technology - Open systems interconnection - Conformance testing methodology and interconnection - Part 2: Abstract test suite specification. (See also ITU Recommendation X.291(1995)).
- [3] Private Network-Network Interface Specification Version 1.0, ATM Forum af-pnni-0055.000, March 1996
- [4] PNNI v1.0 Errata and PICS, ATM Forum af-pnni-0081.000, May 1997
- [5] ATM Inter-Network Interface (AINI) Specifications, ATM Forum af-cs-0125.000, April 1999

#### **C.1.3 Definitions**

This document uses the following terms defined in ISO/IEC 9646-1[1]:

- A Protocol Implementation Conformance Statement (PICS) is a statement made by the supplier of an implementation or system, stating which capabilities have been implemented for a given protocol.
- A PICS proforma is a document, in the form of a questionnaire, designed by the protocol specifier or conformance test suite specifier, which when completed for an implementation or system becomes the PICS.

#### **C.1.4 Acronyms**

IE	Information Element
IUT	Implementation Under Test
M	Mandatory requirements (these are to be observed in all cases)

- O Optional (may be selected to suit the implementation, provided that any requirements applicable to the options are observed)
- NCCI Network Call Correlation Identifier
- O.n Optional, but support is required for either at least one or only one of the options in the group labeled with the same numeral "n".
- PICS Protocol Implementation Conformance Statement

### **C.1.5 Conformance**

The supplier of a protocol implementation which is claimed to conform to the ATM Forum Network Call Correlation Identifier v1.0 for AINI v1.0 is required to complete a copy of the PICS proforma provided in this document and is required to provide the information necessary to identify both the supplier and the implementation.

## **C.2 Identification of the Implementation**

### **Implementation Under Test (IUT) Identification**

IUT Name: \_\_\_\_\_

IUT Version: \_\_\_\_\_

\_\_\_\_\_

### **System Under Test (SUT) Identification**

SUT Name: \_\_\_\_\_

Hardware Configuration: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Operating System: \_\_\_\_\_

### **Product Supplier**

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Telephone Number: \_\_\_\_\_

Facsimile Number: \_\_\_\_\_

Email Address: \_\_\_\_\_

Additional Information: \_\_\_\_\_

**Client**

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Telephone Number: \_\_\_\_\_

Facsimile Number: \_\_\_\_\_

Email Address: \_\_\_\_\_

Additional Information: \_\_\_\_\_

**PICS Contact Person**

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Telephone Number: \_\_\_\_\_

Facsimile Number: \_\_\_\_\_

Email Address: \_\_\_\_\_

Additional Information: \_\_\_\_\_

**PICS/System Conformance Statement**

Provide the relationship of the PICS with the System Conformance Statement for the system:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

**Identification of the protocol**

This PICS proforma applies to the following:

\* ATM Forum Network Call Correlation Identifier v1.0 for AINI v1.0.

### **C.3 PICS Proforma**

#### **C.3.1 Global statement of conformance**

The implementation described in this PICS meets all of the mandatory requirements of the reference protocol.

YES

NO

Note: Answering "No" indicates non-conformance to the specified protocol. Non-supported mandatory capabilities are to be identified in the following tables, with an explanation by the implementor explaining why the implementation is non-conforming.

#### **C.3.2 Instructions for Completing the PICS Proforma**

The PICS Proforma is a fixed-format questionnaire. Answers to the questionnaire should be provided in the rightmost columns, either by simply indicating a restricted choice (such as Yes or No), or by entering a value or a set of range of values.

*A supplier may also provide additional information, categorized as exceptional or supplementary information. These additional information should be provided as items labeled X.<i> for exceptional information, or S.<i> for supplemental information, respectively, for cross reference purposes, where <i> is any unambiguous identification for the item. The exception and supplementary information are not mandatory and the PICS is complete without such information. The presence of optional supplementary or exception information should not affect test execution, and will in no way affect interoperability verification. The column labeled 'Reference' gives a pointer to sections of the protocol specification for which the PICS Proforma is being written.*

### C.4 Roles

Item	Roles Does the IUT of the NCCI addendum to AINI...	Status	Prerequisite	Reference	Support
NCCI-PP	The NCCI feature for Point-to-Point calls ?	M		1.1	[ ]Yes [ ]No
NCCI-PM	The NCCI feature for Point-to-Multipoint calls ?	M	AINI/ (Note 1)	1.1	[ ]Yes [ ]No
Comments: Note 1: Provided that the support for Point-to-Multipoint calls is implemented at the AINI.					

Table 1: Roles (AINI)

### C.5 NCCI encoding

Item	NCCI formats and encoding Is the IUT capable of...	Status	Prerequisite	Reference	Support
NCCI-E-1	Generating a NCCI information element as described in Figure 2-1?	M		2, 4.2.1, 4.2.2	[ ]Yes [ ]No
NCCI-E-2	Generating a NCCI information element with the IE instruction field flag set to 1?	O		7	[ ]Yes [ ]No
NCCI-E-3	Generating a NCCI information element with the "pass along request" bit set to 0?	O		7	[ ]Yes [ ]No
NCCI-E-4	Generating a NCCI information element with the IE action indicator set to "Discard information element and proceed"?	O		7	[ ]Yes [ ]No
NCCI-E-5	Generating a NCCI information element with a NCCI value in a AESA-based format ?	O.1		2, 4.2.1, 4.2.2	[ ]Yes [ ]No
NCCI-E-6	Generating a NCCI information element with a NCCI value in a B-ISUP format ?	O.1		2, 4.2.1, 4.2.2	[ ]Yes [ ]No
NCCI-E-7	Including one NCCI information element in a SETUP message ?	M		4.1	[ ]Yes [ ]No
NCCI-E-8	Including one NCCI information element in an ADD PARTY message ?	M	NCCI-PM	4.1	[ ]Yes [ ]No
NCCI-E-9	Including one NCCI information element in a CONNECT message ?	M		4.1.1	[ ]Yes [ ]No
NCCI-E-10	Including no more than one NCCI information elements in a SETUP message ?	M		4.1	[ ]Yes [ ]No
NCCI-E-11	Including no more than one NCCI information elements in an ADD PARTY message ?	M	NCCI-PM	4.1	[ ]Yes [ ]No
NCCI-E-12	Including no more than one NCCI information elements in a CONNECT message ?	M		4.1.1	[ ]Yes [ ]No
Comments: O.1. = mandatory to support one of these NCCI formats.					

Table 2: NCCI encoding (AINI)

### C.6 NCCI capabilities for Point-to-Point calls

Prerequisite: NCCI-PP

Item	Capabilities for Point-to-Point calls Is the IUT capable of ...	Status	Prerequisite	Reference	Support
NCCI-PPC-1	Assigning a NCCI when establishing a call for a Point-to-Point VCC ?	M		1.1	[ ]Yes [ ]No
NCCI-PPC-2	Assigning a NCCI when establishing a call for a Point-to-Point VPC ?	M	OPT_6/PNNI Errata & PICS	1.1	[ ]Yes [ ]No
NCCI-PPC-3	Assigning a NCCI when establishing a call for a Point-to-Point Soft PVC ?	M	OPT_7/PNNI Errata & PICS	1.1	[ ]Yes [ ]No
NCCI-PPC-4	Assigning a NCCI when establishing a call for a Point-to-Point Soft PVP ?	M	OPT_7/PNNI Errata & PICS	1.1	[ ]Yes [ ]No
NCCI-PPC-5	At the preceding side, receiving and processing a setup request for a Point-to-Point call containing a NCCI , and forwarding the NCCI IE to the succeeding node as received?	M		4.2.1	[ ] Yes [ ] No
NCCI-PPC-6	At the preceding side, receiving and processing a setup request for a Point-to-Point call containing a NCCI , and discarding the NCCI?	M		4.2.1	[ ]Yes [ ]No
NCCI-PPC-7	At the preceding side, receiving and processing a setup request for a Point-to-Point call not containing a NCCI, and assigning a NCCI?	M		4.2.1	[ ]Yes [ ]No
NCCI-PPC-8	At the preceding side, receiving and processing a CONNECT message for a Point-to-Point call containing a NCCI IE, and discarding the NCCI IE ?	M		4.2.1	[ ]Yes [ ]No
NCCI-PPC-9	At the succeeding side, receiving and processing a SETUP message for a Point-to-Point call containing a NCCI IE and forwarding the NCCI IE to the preceding side of the next interface as received ?	M		4.2.1	[ ]Yes [ ]No
NCCI-PPC-10	At the succeeding side, receiving and processing a SETUP message for a Point-to-Point call containing a NCCI IE, and discarding the NCCI IE?	M		4.2.1	[ ]Yes [ ]No
NCCI-PPC-11	At the succeeding side, receiving and processing a SETUP message for a Point-to-Point call containing a NCCI IE, discarding the NCCI IE and assigning a new NCCI ?	M		4.2.1	[ ]Yes [ ]No
NCCI-PPC-12	At the succeeding side, receiving and processing a SETUP message for a Point-to-Point call not containing a NCCI IE, and assigning a NCCI?	M		4.2.1	[ ]Yes [ ]No
NCCI-PPC-13	At the succeeding side, returning the NCCI assigned by this node in the CONNECT message for a Point-to-Point call ?	M		4.2.1	[ ]Yes [ ]No
Comments:					

Table 3: NCCI capabilities for Point-to-Point calls (AINI)

### C.7 NCCI procedures for Point-to-Point calls

Prerequisite: NCCI-PP

Item	Procedures for Point-to-Point calls Does the IUT ...	Status	Prerequisite	Reference	Support
NCCI-PPP-1	At the preceding side, not assign a NCCI if a received setup request contains a NCCI ?	M		4.2.1	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PPP-2	At the succeeding side, insert the NCCI in the CONNECT message prior to progressing the message towards the preceding side, if a NCCI was assigned by this node during the setup phase?	O		4.2.1	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PPP-3	At the succeeding side, not include the NCCI in the CONNECT message prior to progressing the message towards the preceding side, if no NCCI was assigned by this node during the setup phase?	M		4.2.1	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PPP-4	Guarantee a unique NCCI value for all Point-to-Point connections that are assigned a NCCI at that location over a sufficiently long period of time ?	M		4.2.1	<input type="checkbox"/> Yes <input type="checkbox"/> No
Comments:					

Table 4: NCCI procedures for Point-to-Point calls (AINI)

### C.8 NCCI capabilities for Point-to-Multipoint calls

Prerequisite: NCCI-PM

Item	Capabilities for Point-to-Multipoint calls : Is the IUT capable of ...	Status	Prerequisite	Reference	Support
NCCI-PMC-1	Assigning a NCCI when establishing a call for a Point-to-Multipoint VCC ?	M		1.1	[ ]Yes [ ]No
NCCI-PMC-2	Assigning a NCCI when establishing a call for a Point-to-Multipoint VPC ?	M	OPT_6/PNNI Errata & PICS	1.1	[ ]Yes [ ]No
NCCI-PMC-3	Assigning a NCCI when establishing a call for a Point-to-Multipoint Soft PVC ?	M	OPT_7/PNNI Errata & PICS	1.1	[ ]Yes [ ]No
NCCI-PMC-4	Assigning a NCCI when establishing a call for a Point-to-Multipoint Soft PVP ?	M	OPT_7/PNNI Errata & PICS	1.1	[ ]Yes [ ]No
NCCI-PMC-5	At the preceding side, receiving and processing a setup request for a Point-to-Multipoint call containing a NCCI, and forwarding the NCCI IE to the succeeding node as received?	M		4.2.2.1	[ ] Yes [ ] No
NCCI-PMC-6	At the preceding side, receiving and processing a setup request for a Point-to-Multipoint call containing a NCCI, and discarding the NCCI?	M		4.2.2.1	[ ]Yes [ ]No
NCCI-PMC-7	At the preceding side, receiving and processing a setup request for a Point-to-Multipoint call not containing a NCCI, and assigning a NCCI ?	M		4.2.2.1	[ ]Yes [ ]No
NCCI-PMC-8	At the preceding side, receiving and processing an add party request for a Point-to-Multipoint call containing a NCCI, and forwarding the NCCI IE to the succeeding node as received?	M		4.2.2.1, 4.2.2.2	[ ] Yes [ ] No
NCCI-PMC-9	At the preceding side, receiving and processing an add party request for a Point-to-Multipoint call containing a NCCI, and discarding the NCCI?	M		4.2.2.1, 4.2.2.2	[ ]Yes [ ]No
NCCI-PMC-10	At the preceding side, receiving and processing an add party request for a Point-to-Multipoint call not containing a NCCI, and inserting in the ADD PARTY message forwarded to the succeeding node the same NCCI as assigned in the SETUP message?	M		4.2.2.1, 4.2.2.2	[ ]Yes [ ]No
NCCI-PMC-11	At the preceding side, receiving and processing a CONNECT message for a Point-to-Multipoint call containing a NCCI IE, and discarding the NCCI IE ?	M		4.2.2.1	[ ]Yes [ ]No
NCCI-PMC-12	At the succeeding side, receiving and processing a SETUP message for a Point-to-Multipoint call containing a NCCI IE and forwarding the NCCI IE to the preceding side of the next interface as received ?	M		4.2.2.1	[ ]Yes [ ]No
NCCI-PMC-13	At the succeeding side, receiving and processing a SETUP message for a Point-to-Multipoint call containing a NCCI IE, and discarding the NCCI?	M		4.2.2.1	[ ]Yes [ ]No
NCCI-PMC-14	At the succeeding side, receiving and processing a SETUP message for a Point-to-Multipoint call containing a NCCI IE, discarding the NCCI and assigning a new NCCI?	M		4.2.2.1	[ ]Yes [ ]No

NCCI-PMC-15	At the succeeding side, receiving and processing a SETUP message for a Point-to-Multipoint call not containing a NCCI IE, and assigning a NCCI ?	M		4.2.2.1	[ ]Yes [ ]No
NCCI-PMC-16	At the succeeding side, receiving and processing an ADD PARTY message for a Point-to-Multipoint call containing a NCCI IE and forwarding the NCCI IE to the preceding side of the next interface as received ?	M		4.2.2.2	[ ]Yes [ ]No
NCCI-PMC-17	At the succeeding side, receiving and processing an ADD PARTY message for a Point-to-Multipoint call containing a NCCI IE, and discarding the NCCI ?	M		4.2.2.2	[ ]Yes [ ]No
NCCI-PMC-18	At the succeeding side, receiving and processing an ADD PARTY message for a Point-to-Multipoint call, and inserting in the add party indication forwarded to the preceding side of the next interface the same NCCI as assigned in the setup indication?	M		4.2.2.2	[ ]Yes [ ]No
NCCI-PMC-19	At the succeeding side, returning the NCCI assigned by this node in the CONNECT message for a Point-to-Point call ?	M		4.2.2.1	[ ]Yes [ ]No
NCCI-PMC-20	Storing the NCCIs associated with Point-to-Multipoint calls when assigned by this implementation?	M		4.2.3	[ ]Yes [ ]No
Comments:					

Table 5: NCCI capabilities for Point-to-Multipoint calls (AINI)

### C.9 NCCI procedures for Point-to-Multipoint calls

Prerequisite: NCCI-PM

Item	Procedures for Point-to-Multipoint calls : Does the IUT...	Status	Prerequisite	Reference	Support
NCCI-PMP-1	At the preceding side, convert an add party request into a SETUP message by following the procedures of section 4.2.2.1?	M		4.2.2.1	[ ]Yes [ ] No
NCCI-PMP-2	At the preceding side, not assign a NCCI when receiving a setup request containing a NCCI ?	M		4.2.2.1	[ ]Yes [ ]No
NCCI-PMP-3	At the preceding side, forward the NCCI IE as received if a received add party request contains a NCCI and the initial setup request contained a NCCI which was forwarded?	M		4.2.2.2	[ ]Yes [ ] No
NCCI-PMP-4	At the preceding side, not include any NCCI IE in subsequent ADD PARTY messages if the initial SETUP message did not contain a NCCI IE?	M		4.2.2.2	[ ]Yes [ ]No
NCCI-PMP-5	At the preceding side, if a NCCI was assigned and contained in the initial SETUP message, include the NCCI IE in all subsequent ADD PARTY messages ?	M		4.2.2.2	[ ]Yes [ ]No

NCCI-PMP-6	At the succeeding side, forward the NCCI as received if the initial SETUP message contained a NCCI IE which has been forwarded?	M		4.2.2.2	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PMP-7	At the succeeding side, not include any NCCI in subsequent add party indications if the initial setup indication did not contain a NCCI?	M		4.2.2.2	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PMP-8	At the succeeding side, if a NCCI was assigned and contained in the initial request, include the NCCI in all subsequent add party request?	M		4.2.2.2	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PMP-9	Store the NCCIs associated with Point-to-Multipoint calls when assigned by this implementation?	M		4.2.3	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PMP-10	Guarantee a unique NCCI value for all Point-to-Multipoint calls that are assigned a NCCI at that location over a sufficiently long period of time ?	M		4.2.2.1	<input type="checkbox"/> Yes <input type="checkbox"/> No
Comments:					

Table 6: NCCI procedures for Point-to-Multipoint calls (AINI)

## **Annex D. NCCI PICS Proforma for UNI v4.0**

### **D.1 Introduction**

To evaluate conformance of a particular implementation, it is necessary to have a statement of which capabilities and options that have been implemented. Such a statement is called a Protocol Implementation Conformance Statement (PICS).

#### **D.1.1 Scope**

This document provides the PICS proforma for the Network Call Correlation Identifier v1.0 for UNI v4.0, as specified in this document in compliance with the relevant requirements, and in accordance with the relevant guidelines, given in ISO/IEC 9646-2[2]. In most cases, statements contained in notes in the specification, which were intended as information, are not included in the PICS.

#### **D.1.2 Normative References**

- [1] ISO/IEC 9646-1:1994, Information technology - Open systems interconnection - Conformance testing methodology and framework - Part 1: General Concepts. (See also ITU Recommendation X.290(1995)).
- [2] ISO/IEC 9646-2:1994, Information technology - Open systems interconnection - Conformance testing methodology and interconnection - Part 2: Abstract test suite specification. (See also ITU Recommendation X.291(1995)).
- [3] ATM User-Network Interface (UNI) Signalling Specification, ATM Forum af-sig-0061.000, July 1996

#### **D.1.3 Definitions**

This document uses the following terms defined in ISO/IEC 9646-1[1]:

- A Protocol Implementation Conformance Statement (PICS) is a statement made by the supplier of an implementation or system, stating which capabilities have been implemented for a given protocol.
- A PICS proforma is a document, in the form of a questionnaire, designed by the protocol specifier or conformance test suite specifier, which when completed for an implementation or system becomes the PICS.

#### **D.1.4 Acronyms**

IE	Information Element
IUT	Implementation Under Test
M	Mandatory requirements (these are to be observed in all cases)
O	Optional (may be selected to suit the implementation, provided that any requirements applicable to the options are observed)
NCCI	Network Call Correlation Identifier

O.n           Optional, but support is required for either at least one or only one of the options in the group labeled with the same numeral "n".

PICS           Protocol Implementation Conformance Statement

### **D.1.5 Conformance**

The supplier of a protocol implementation which is claimed to conform to the ATM Forum Network Call Correlation Identifier v1.0 for UNI v4.0 is required to complete a copy of the PICS proforma provided in this document and is required to provide the information necessary to identify both the supplier and the implementation.

## **D.2 Identification of the Implementation**

### **Implementation Under Test (IUT) Identification**

IUT Name: \_\_\_\_\_

IUT Version: \_\_\_\_\_

\_\_\_\_\_

### **System Under Test (SUT) Identification**

SUT Name: \_\_\_\_\_

Hardware Configuration: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Operating System: \_\_\_\_\_

### **Product Supplier**

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Telephone Number: \_\_\_\_\_

Facsimile Number: \_\_\_\_\_

Email Address: \_\_\_\_\_

Additional Information: \_\_\_\_\_

**Client**

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Telephone Number: \_\_\_\_\_

Facsimile Number: \_\_\_\_\_

Email Address: \_\_\_\_\_

Additional Information: \_\_\_\_\_

**PICS Contact Person**

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Telephone Number: \_\_\_\_\_

Facsimile Number: \_\_\_\_\_

Email Address: \_\_\_\_\_

Additional Information: \_\_\_\_\_

**PICS/System Conformance Statement**

Provide the relationship of the PICS with the System Conformance Statement for the system:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

**Identification of the protocol**

This PICS proforma applies to the following:

\* ATM Forum Network Call Correlation Identifier v1.0 for UNI v4.0.

### **D.3 PICS Proforma**

#### **D.3.1 Global statement of conformance**

The implementation described in this PICS meets all of the mandatory requirements of the reference protocol.

YES

NO

Note: Answering "No" indicates non-conformance to the specified protocol. Non-supported mandatory capabilities are to be identified in the following tables, with an explanation by the implementor explaining why the implementation is non-conforming.

#### **D.3.2 Instructions for Completing the PICS Proforma**

The PICS Proforma is a fixed-format questionnaire. Answers to the questionnaire should be provided in the rightmost columns, either by simply indicating a restricted choice (such as Yes or No), or by entering a value or a set of range of values.

*A supplier may also provide additional information, categorized as exceptional or supplementary information. These additional information should be provided as items labeled X.<i> for exceptional information, or S.<i> for supplemental information, respectively, for cross reference purposes, where <i> is any unambiguous identification for the item. The exception and supplementary information are not mandatory and the PICS is complete without such information. The presence of optional supplementary or exception information should not affect test execution, and will in no way affect interoperability verification. The column labeled 'Reference' gives a pointer to sections of the protocol specification for which the PICS Proforma is being written.*

## D.4 Roles

Item	Roles Does the IUT of the NCCI addendum to UNI support ...	Status	Prerequisite	Reference	Support
NCCI-PP-U	The NCCI feature for Point-to-Point calls at the user side?	O.1		1.1	[ ]Yes [ ]No
NCCI-PP-N	The NCCI feature for Point-to-Point calls at the network side?	O.1		1.1	[ ]Yes [ ]No
NCCI-PM-U	The NCCI feature for Point-to-Multipoint calls at the user side?	O.2	UNI / (Note 1)	1.1	[ ]Yes [ ]No
NCCI-PM-N	The NCCI feature for Point-to-Multipoint calls at the network side?	O.2	UNI	1.1	[ ]Yes [ ]No
<p>Comments:</p> <p>Note 1: Provided that the support for Point-to-Multipoint calls is implemented at the UNI.</p> <p>O.1: Mandatory to support one of these roles</p> <p>O.2: Mandatory to support one of these roles</p>					

Table 1: Roles

## D.5 NCCI encoding

Item	NCCI formats and encoding Is the IUT capable of...	Status	Prerequisite	Reference	Support
NCCI-E-1	Generating a NCCI information element as described in Figure 2-1?	M		2, 5.2.1, 5.2.2	[ ]Yes [ ]No
NCCI-E-2	Generating a NCCI information element with the IE instruction field flag set to 1?	O		7	[ ]Yes [ ]No
NCCI-E-3	Generating a NCCI information element with the IE action indicator set to "Discard information element and proceed"?	O		7	[ ]Yes [ ]No
NCCI-E-4	Generating a NCCI information element with a NCCI value in a AESA-based format ?	O.1		2, 5.2.1, 5.2.2	[ ]Yes [ ]No
NCCI-E-5	Generating a NCCI information element with a NCCI value in a B-ISUP format ?	O.1		2, 5.2.1, 5.2.2	[ ]Yes [ ]No
NCCI-E-6	Including one NCCI information element in a SETUP message ?	M		5.1.1	[ ]Yes [ ]No
NCCI-E-7	Including one NCCI information element in an ADD PARTY message ?	M	NCCI-PM-N, NCCI-PM-U	5.1.2	[ ]Yes [ ]No
NCCI-E-8	Including one NCCI information element in a CONNECT message ?	M		5.1.3	[ ]Yes [ ]No
NCCI-E-9	Including no more than one NCCI information elements in a SETUP message ?	M		5.1.1	[ ]Yes [ ]No
NCCI-E-10	Including no more than one NCCI information elements in an ADD PARTY message ?	M	NCCI-PM-N, NCCI-PM-U	5.1.2	[ ]Yes [ ]No
NCCI-E-11	Including no more than one NCCI information elements in a CONNECT message ?	M		5.1.3	[ ]Yes [ ]No

Comments:  
 O.1. = mandatory to support one of these NCCI formats.

Table 2: NCCI encoding (UNI)

### D.6 NCCI capabilities for Point-to-Point calls at the user side

Prerequisite: NCCI-PP-U

Item	Capabilities for Point-to-Point calls Is the IUT capable of ...	Status	Prerequisite	Reference	Support
NCCI-PPC-U-1	Assigning a NCCI when establishing a call for a Point-to-Point VCC ?	M		1.1	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PPC-U-2	Assigning a NCCI when establishing a call for a Point-to-Point VPC ?	M		1.1	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PPC-U-3	At the user side of the originating interface, receiving and processing a setup request for a Point-to-Point call containing a NCCI, and forwarding the NCCI IE to the succeeding node as received?	M		5.2.1.1	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PPC-U-4	At the user side of the originating interface, receiving and processing a setup request for a Point-to-Point call containing a NCCI, and discarding the NCCI?	M		5.2.1.1	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PPC-U-5	At the user side of the originating interface, receiving and processing a setup request for a Point-to-Point call not containing a NCCI, and assigning a NCCI?	M		5.2.1.1	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PPC-U-6	At the user side of the originating interface, receiving and processing a CONNECT message for a Point-to-Point call containing a NCCI IE, and discarding the NCCI IE ?	M		5.2.1.1	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PPC-U-7	At the user side of the destination interface, receiving and processing a SETUP message for a Point-to-Point call containing a NCCI IE and forwarding the NCCI IE to the preceding side of the next interface as received ?	M		5.2.1.2	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PPC-U-8	At the user side of the destination interface, receiving and processing a SETUP message for a Point-to-Point call containing a NCCI IE, and discarding the NCCI IE?	M		5.2.1.2	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PPC-U-9	At the user side of the destination interface, receiving and processing a SETUP message for a Point-to-Point call containing a NCCI IE, discarding the NCCI IE and assigning a new NCCI ?	M		5.2.1.2	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PPC-U-10	At the user side of the destination interface, receiving and processing a SETUP message for a Point-to-Point call not containing a NCCI IE, and assigning a NCCI?	M		5.2.1.2	<input type="checkbox"/> Yes <input type="checkbox"/> No

NCCI-PPC-U-11	At the user side of the destination interface, returning the NCCI assigned by this node in the CONNECT message for a Point-to-Point call ?	M		5.2.1.2	<input type="checkbox"/> Yes <input type="checkbox"/> No
Comments:					

Table 3: NCCI capabilities for Point-to-Point calls (UNI - user side)

### D.7 NCCI procedures for Point-to-Point calls at the user side

Prerequisite: NCCI-PP-U

Item	Procedures for Point-to-Point calls Does the IUT ...	Status	Prerequisite	Reference	Support
NCCI-PPP-U-1	At the user side of the originating interface, not assign a NCCI if a received setup request contains a NCCI ?	M		5.2.1.1	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PPP-U-2	At the user side of the destination interface, insert the NCCI in the CONNECT message prior to progressing the message towards the preceding side, if a NCCI was assigned by this node during the setup phase?	O		5.2.1.2	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PPP-U-3	At the user side of the destination interface, not include the NCCI in the CONNECT message prior to progressing the message towards the preceding side, if no NCCI was assigned by this node during the setup phase?	M		5.2.1.2	<input type="checkbox"/> Yes <input type="checkbox"/> No
NCCI-PPP-U-4	Guarantee a unique NCCI value for all Point-to-Point connections that are assigned a NCCI at that location over a sufficiently long period of time ?	M		5.2.1.1, 5.2.1.2	<input type="checkbox"/> Yes <input type="checkbox"/> No
Comments:					

Table 4: NCCI procedures for Point-to-Point calls (UNI - user side)

### D.8 NCCI capabilities for Point-to-Multipoint calls at the user side

Prerequisite: NCCI-PM-U

Item	Capabilities for Point-to-Multipoint calls : Is the IUT capable of ...	Status	Prerequisite	Reference	Support
NCCI-PMC-U-1	Assigning a NCCI when establishing a call for a Point-to-Multipoint VCC ?	M		1.1	[ ]Yes [ ]No
NCCI-PMC-U-2	Assigning a NCCI when establishing a call for a Point-to-Multipoint VPC ?	M		1.1	[ ]Yes [ ]No
NCCI-PMC-U-3	At the user side of the originating interface, receiving and processing a setup request for a Point-to-Multipoint call containing a NCCI, and forwarding the NCCI IE to the succeeding node as received?	M		5.2.2.1.1	[ ] Yes [ ] No
NCCI-PMC-U-4	At the user side of the originating interface, receiving and processing a setup request for a Point-to-Multipoint call containing a NCCI, and discarding the NCCI?	M		5.2.2.1.1	[ ]Yes [ ]No
NCCI-PMC-U-5	At the user side of the originating interface, receiving and processing a setup request for a Point-to-Multipoint call not containing a NCCI, and assigning a NCCI ?	M		5.2.2.1.1	[ ]Yes [ ]No
NCCI-PMC-U-6	At the user side of the originating interface, receiving and processing an add party request for a Point-to-Multipoint call containing a NCCI, and forwarding the NCCI IE to the succeeding node as received?	M		5.2.2.1.1, 5.2.2.1.2	[ ] Yes [ ] No
NCCI-PMC-U-7	At the user side of the originating interface, receiving and processing an add party request for a Point-to-Multipoint call containing a NCCI, and discarding the NCCI?	M		5.2.2.1.1, 5.2.2.1.2	[ ]Yes [ ]No
NCCI-PMC-U-8	At the user side of the originating interface, receiving and processing an add party request for a Point-to-Multipoint call not containing a NCCI, and inserting in the ADD PARTY message forwarded to the succeeding node the same NCCI as assigned in the SETUP message?	M		5.2.2.1.1, 5.2.2.1.2	[ ]Yes [ ]No
NCCI-PMC-U-9	At the user side of the originating interface, receiving and processing a CONNECT message for a Point-to-Point call containing a NCCI IE, and discarding the NCCI IE ?	M		5.2.2.1.1	[ ]Yes [ ]No
NCCI-PMC-U-10	At the user side of the destination interface, receiving and processing a SETUP message for a Point-to-Multipoint call containing a NCCI IE and forwarding the NCCI IE to the preceding side of the next interface as received ?	M		5.2.2.2.1	[ ]Yes [ ]No
NCCI-PMC-U-11	At the user side of the destination interface, receiving and processing a SETUP message for a Point-to-Multipoint call containing a NCCI IE, and discarding the NCCI?	M		5.2.2.2.1	[ ]Yes [ ]No

NCCI-PMC-U-12	At the user side of the destination interface, receiving and processing a SETUP message for a Point-to-Multipoint call containing a NCCI IE, discarding the NCCI and assigning a new NCCI?	M		5.2.2.2.1	[ ]Yes [ ]No
NCCI-PMC-U-13	At the user side of the destination interface, receiving and processing a SETUP message for a Point-to-Multipoint call not containing a NCCI IE, and assigning a NCCI ?	M		5.2.2.2.1	[ ]Yes [ ]No
NCCI-PMC-U-14	At the user side of the destination interface, receiving and processing an ADD PARTY message for a Point-to-Multipoint call containing a NCCI IE and forwarding the NCCI IE to the preceding side of the next interface as received ?	M		5.2.2.2.2	[ ]Yes [ ]No
NCCI-PMC-U-15	At the user side of the destination interface, receiving and processing an ADD PARTY message for a Point-to-Multipoint call containing a NCCI IE, and discarding the NCCI ?	M		5.2.2.2.2	[ ]Yes [ ]No
NCCI-PMC-U-16	At the user side of the destination interface, receiving and processing an ADD PARTY message for a Point-to-Multipoint call, and inserting in the add party indication forwarded to the preceding side of the next interface the same NCCI as assigned in the setup indication?	M		5.2.2.2.2	[ ]Yes [ ]No
NCCI-PMC-U-17	At the user side of the destination interface, returning the NCCI assigned by this node in the CONNECT message for a Point-to-Point call ?	M		5.2.2.2.1	[ ]Yes [ ]No
NCCI-PMC-U-18	Storing the NCCIs associated with Point-to-Multipoint calls when assigned by this implementation?	M		5.2.3	[ ]Yes [ ]No
Comments:					

Table 5: NCCI capabilities for Point-to-Multipoint calls (UNI - user side)

### D.9 NCCI procedures for Point-to-Multipoint calls at the user side

Prerequisite: NCCI-PM-U

Item	Procedures for Point-to-Multipoint calls : Does the IUT...	Status	Prerequisite	Reference	Support
NCCI-PMP-U-1	At the user side of the originating interface, convert an add party request into a SETUP message by following the procedures of section 5.2.2.1.1?	M		5.2.2.1.1	[ ]Yes [ ]No
NCCI-PMP-U-2	At the user side of the originating interface, not assign a NCCI when receiving a setup request containing a NCCI ?	M		5.2.2.1.1	[ ]Yes [ ]No

NCCI-PMP-U-3	At the user side of the originating interface, forward the NCCI IE as received if a received add party request contains a NCCI and the initial setup request contained a NCCI which was forwarded?	M		5.2.2.1.2	[ ]Yes [ ]No
NCCI-PMP-U-4	At the user side of the originating interface, not include any NCCI IE in subsequent ADD PARTY messages if the initial SETUP message did not contain a NCCI IE?	M		5.2.2.1.2	[ ]Yes [ ]No
NCCI-PMP-U-5	At the user side of the originating interface, if a NCCI was assigned and contained in the initial SETUP message, include the NCCI IE in all subsequent ADD PARTY messages ?	M		5.2.2.1.2	[ ]Yes [ ]No
NCCI-PMP-U-6	At the user side of the destination interface, forward the NCCI as received if the initial SETUP message contained a NCCI IE which has been forwarded?	M		5.2.2.2.2	[ ]Yes [ ]No
NCCI-PMP-U-7	At the user side of the destination interface, not include any NCCI in subsequent add party indications if the initial setup indication did not contain a NCCI?	M		5.2.2.2.2	[ ]Yes [ ]No
NCCI-PMP-U-8	At the succeeding side, if a NCCI was assigned and contained in the initial request, include the NCCI in all subsequent add party request?	M		5.2.2.2.2	[ ]Yes [ ]No
NCCI-PMP-U-9	Store the NCCIs associated with Point-to-Multipoint calls when assigned by this implementation?	M		5.2.3	[ ]Yes [ ]No
NCCI-PMP-U-10	Guarantee a unique NCCI value for all Point-to-Multipoint calls that are assigned a NCCI at that location over a sufficiently long period of time ?	M		5.2.2.1.1, 5.2.2.2.1	[ ]Yes [ ]No
Comments:					

Table 6: NCCI procedures for Point-to-Multipoint calls (UNI - user side)

### D.10 NCCI capabilities for Point-to-Point calls at the network side

Prerequisite: NCCI-PP-N

Item	Capabilities for Point-to-Point calls Is the IUT capable of ...	Status	Prerequisite	Reference	Support
NCCI-PPC-N-1	Assigning a NCCI when establishing a call for a Point-to-Point VCC ?	M		1.1	[ ]Yes [ ]No
NCCI-PPC-N-2	Assigning a NCCI when establishing a call for a Point-to-Point VPC ?	M		1.1	[ ]Yes [ ]No
NCCI-PPC-N-3	At the network side of the destination interface, receiving and processing a setup request for a Point-to-Point call containing a NCCI, and forwarding the NCCI IE to the succeeding node as received?	M		5.2.1.2	[ ] Yes [ ] No

NCCI-PPC-N-4	At the network side of the destination interface, receiving and processing a setup request for a Point-to-Point call containing a NCCI, and discarding the NCCI?	M		5.2.1.2	[ ]Yes [ ]No
NCCI-PPC-N-5	At the network side of the destination interface, receiving and processing a setup request for a Point-to-Point call not containing a NCCI, and assigning a NCCI?	M		5.2.1.2	[ ]Yes [ ]No
NCCI-PPC-N-6	At the network side of the destination interface, receiving and processing a CONNECT message for a Point-to-Point call containing a NCCI IE, and discarding the NCCI IE ?	M		5.2.1.2	[ ]Yes [ ]No
NCCI-PPC-N-7	At the network side of the originating interface, receiving and processing a SETUP message for a Point-to-Point call containing a NCCI IE and forwarding the NCCI IE to the preceding side of the next interface as received ?	M		5.2.1.1	[ ]Yes [ ]No
NCCI-PPC-N-8	At the network side of the originating interface, receiving and processing a SETUP message for a Point-to-Point call containing a NCCI IE, and discarding the NCCI IE?	M		5.2.1.1	[ ]Yes [ ]No
NCCI-PPC-N-9	At the network side of the originating interface, receiving and processing a SETUP message for a Point-to-Point call containing a NCCI IE, discarding the NCCI IE and assigning a new NCCI ?	M		5.2.1.1	[ ]Yes [ ]No
NCCI-PPC-N-10	At the network side of the originating interface, receiving and processing a SETUP message for a Point-to-Point call not containing a NCCI IE, and assigning a NCCI?	M		5.2.1.1	[ ]Yes [ ]No
NCCI-PPC-N-11	At the network side of the originating interface, returning the NCCI assigned by this node in the CONNECT message for a Point-to-Point call ?	M		5.2.1.1	[ ]Yes [ ]No
Comments:					

Table 7: NCCI capabilities for Point-to-Point calls (UNI - network side)

### D.11 NCCI procedures for Point-to-Point calls at the network side

Prerequisite: NCCI-PP-N

Item	Procedures for Point-to-Point calls Does the IUT ...	Status	Prerequisite	Reference	Support
NCCI-PPP-N-1	At the network side of the destination interface, not assign a NCCI if a received setup request contains a NCCI ?	M		5.2.1.2	[ ]Yes [ ]No
NCCI-PPP-N-2	At the network side of the originating interface, insert the NCCI in the CONNECT message prior to progressing the message towards the preceding side, if a NCCI was assigned by this node during the setup phase?	O		5.2.1.1	[ ] Yes [ ] No

NCCI-PPP-N-3	At the network side of the originating interface, not include the NCCI in the CONNECT message prior to progressing the message towards the preceding side, if no NCCI was assigned by this node during the setup phase?	M		5.2.1.1	[ ] Yes [ ] No
NCCI-PPP-N-4	Guarantee a unique NCCI value for all Point-to-Point connections that are assigned a NCCI at that location over a sufficiently long period of time ?	M		5.2.1.1, 5.2.1.2	[ ]Yes [ ]No
Comments:					

Table 8: NCCI procedures for Point-to-Point calls (UNI - network side)

## D.12 NCCI capabilities for Point-to-Multipoint calls at the network side

Prerequisite: NCCI-PM-N

Item	Capabilities for Point-to-Multipoint calls : Is the IUT capable of ...	Status	Prerequisite	Reference	Support
NCCI-PMC-N-1	Assigning a NCCI when establishing a call for a Point-to-Multipoint VCC ?	M		1.1	[ ]Yes [ ]No
NCCI-PMC-N-2	Assigning a NCCI when establishing a call for a Point-to-Multipoint VPC ?	M		1.1	[ ]Yes [ ]No
NCCI-PMC-N-3	At the network side of the destination interface, receiving and processing a setup request for a Point-to-Multipoint call containing a NCCI, and forwarding the NCCI IE to the succeeding node as received?	M		5.2.2.2.1	[ ] Yes [ ] No
NCCI-PMC-N-4	At the network side of the destination interface, receiving and processing a setup request for a Point-to-Multipoint call containing a NCCI, and discarding the NCCI?	M		5.2.2.2.1	[ ]Yes [ ]No
NCCI-PMC-N-5	At the network side of the destination interface, receiving and processing a setup request for a Point-to-Multipoint call not containing a NCCI, and assigning a NCCI ?	M		5.2.2.2.1	[ ]Yes [ ]No
NCCI-PMC-N-6	At the network side of the destination interface, receiving and processing an add party request for a Point-to-Multipoint call containing a NCCI, and forwarding the NCCI IE to the succeeding node as received?	M		5.2.2.2.1, 5.2.2.2.2	[ ] Yes [ ] No
NCCI-PMC-N-7	At the network side of the destination interface, receiving and processing an add party request for a Point-to-Multipoint call containing a NCCI, and discarding the NCCI?	M		5.2.2.2.1, 5.2.2.2.2	[ ]Yes [ ]No
NCCI-PMC-N-8	At the network side of the destination interface, receiving and processing an add party request for a Point-to-Multipoint call not containing a NCCI, and inserting in the ADD PARTY message forwarded to the succeeding node the same NCCI as assigned in the SETUP message?	M		5.2.2.2.1, 5.2.2.2.2	[ ]Yes [ ]No
NCCI-PMC-N-9	At the network side of the destination interface, receiving and processing a CONNECT message for a Point-to-Point call containing a NCCI IE, and discarding the NCCI IE ?	M		5.2.2.2.1	[ ]Yes [ ]No
NCCI-PMC-N-10	At the network side of the originating interface, receiving and processing a SETUP message for a Point-to-Multipoint call containing a NCCI IE and forwarding the NCCI IE to the preceding side of the next interface as received ?	M		5.2.2.1.1	[ ]Yes [ ]No
NCCI-PMC-N-11	At the network side of the originating interface, receiving and processing a SETUP message for a Point-to-Multipoint call containing a NCCI IE, and discarding the NCCI?	M		5.2.2.1.1	[ ]Yes [ ]No

NCCI-PMC-N-12	At the network side of the originating interface, receiving and processing a SETUP message for a Point-to-Multipoint call containing a NCCI IE, discarding the NCCI and assigning a new NCCI?	M		5.2.2.1.1	[ ]Yes [ ]No
NCCI-PMC-N-13	At the network side of the originating interface, receiving and processing a SETUP message for a Point-to-Multipoint call not containing a NCCI IE, and assigning a NCCI ?	M		5.2.2.1.1	[ ]Yes [ ]No
NCCI-PMC-N-14	At the network side of the originating interface, receiving and processing an ADD PARTY message for a Point-to-Multipoint call containing a NCCI IE and forwarding the NCCI IE to the preceding side of the next interface as received ?	M		5.2.2.1.2	[ ]Yes [ ]No
NCCI-PMC-N-15	At the network side of the originating interface, receiving and processing an ADD PARTY message for a Point-to-Multipoint call containing a NCCI IE, and discarding the NCCI ?	M		5.2.2.1.2	[ ]Yes [ ]No
NCCI-PMC-N-16	At the network side of the originating interface, receiving and processing an ADD PARTY message for a Point-to-Multipoint call, and inserting in the add party indication forwarded to the preceding side of the next interface the same NCCI as assigned in the setup indication?	M		5.2.2.1.2	[ ]Yes [ ]No
NCCI-PMC-N-17	At the network side of the originating interface, returning the NCCI assigned by this node in the CONNECT message for a Point-to-Point call ?	M		5.2.2.1.1	[ ]Yes [ ]No
NCCI-PMC-N-18	Storing the NCCIs associated with Point-to-Multipoint calls when assigned by this implementation?	M		5.2.3	[ ]Yes [ ]No
Comments:					

Table 9: NCCI capabilities for Point-to-Multipoint calls (UNI - network side)

### D.13 NCCI procedures for Point-to-Multipoint calls at the network side

Prerequisite: NCCI-PM-N

Item	Procedures for Point-to-Multipoint calls : Does the IUT...	Status	Prerequisite	Reference	Support
NCCI-PMP-N-1	At the network side of the destination interface, convert an add party request into a SETUP message by following the procedures of section 5.2.2.2.1?	M		5.2.2.2.1	[ ]Yes [ ]No
NCCI-PMP-N-2	At the network side of the destination interface, not assign a NCCI when receiving a setup request containing a NCCI ?	M		5.2.2.2.1	[ ]Yes [ ]No

NCCI-PMP-N-3	At the network side of the destination interface, forward the NCCI IE as received if a received add party request contains a NCCI and the initial setup request contained a NCCI which was forwarded?	M		5.2.2.2.2	[ ]Yes [ ]No
NCCI-PMP-N-4	At the network side of the destination interface, not include any NCCI IE in subsequent ADD PARTY messages if the initial SETUP message did not contain a NCCI IE?	M		5.2.2.2.2	[ ]Yes [ ]No
NCCI-PMP-N-5	At the network side of the destination interface, if a NCCI was assigned and contained in the initial SETUP message, include the NCCI IE in all subsequent ADD PARTY messages ?	M		5.2.2.2.2	[ ]Yes [ ]No
NCCI-PMP-N-6	At the network side of the originating interface, forward the NCCI as received if the initial SETUP message contained a NCCI IE which has been forwarded?	M		5.2.2.1.2	[ ]Yes [ ]No
NCCI-PMP-N-7	At the originating interface, not include any NCCI in subsequent add party indications if the initial setup indication did not contain a NCCI?	M		5.2.2.1.2	[ ]Yes [ ]No
NCCI-PMP-N-8	At the succeeding side, if a NCCI was assigned and contained in the initial request, include the NCCI in all subsequent add party request?	M		5.2.2.1.2	[ ]Yes [ ]No
NCCI-PMP-N-9	Store the NCCIs associated with Point-to-Multipoint calls when assigned by this implementation?	M		5.2.3	[ ]Yes [ ]No
NCCI-PMP-N-10	Guarantee a unique NCCI value for all Point-to-Multipoint calls that are assigned a NCCI at that location over a sufficiently long period of time ?	M		5.2.2.1.1, 5.2.2.2.1	[ ]Yes [ ]No
Comments:					

Table 10: NCCI procedures for Point-to-Multipoint calls (UNI - network side)

## Appendix A. B-ISUP NCCI format

### [Informative]

As shown in Figure A-1 the B-ISUP NCCI format consists of a string of 9 octets. The B-ISUP NCCI is specified in ITU-T Recommendation Q.2726.3 [5] and is divided in three parts:

**Network Identifier** The network identifier consists of a 0 followed by 3 digits representing an E.164 country code padded, if necessary, on the right with 0s (2 octets of 4 BCD digits).

**Point Code** The point code contains the SS7 point code of the node where the NCCI is assigned (3 octets).

**Call Identifier** The call identifier is locally unique at the point where the NCCI is assigned to the connection. The semantic of this field are determined by the assigning entity, however the values chosen shall be such as to guarantee a unique value for all connections that are assigned a NCCI at that location (as identified by the network identifier and the point code) over a long period of time (4 octets).


<b>Net. Id.</b> (2 octets)	<b>Point Code</b> (3 octets)	<b>Call Identifier</b> (4 octets)
-------------------------------	---------------------------------	--------------------------------------

Figure A-1 Format of a B-ISUP Network Call Correlation Identifier (9 octets)

## Appendix B. Example of NCCIs correlation between private and ATM Service Provider networks

### [Informative]

It is desirable to use a single NCCI end-to-end. However, in the case that certain ATM networks (private or public) assign their own NCCIs, then it is useful to be able to correlate these NCCIs. The intent of this annex is to describe a possible way of correlating different NCCIs end-to-end between the private and public networks. The ability to correlate NCCIs shown in this example will only work when there is a single ASP between private networks “S” and “T” or when there are multiple ASPs between private networks “S” and “T” that share the same NCCI. The following Figure B-1 is used as an example.



**Figure B-1 Example of the networks interconnection when transporting NCCIs**

1. The ingress edge switch (i.e. connecting to UNI "A") of the Private Network "S" assigns its own NCCI-S which is propagated to its egress edge switch (i.e. connecting to AINI "X"). However, the NCCI-S is not forwarded to the network side of the AINI "X".
2. The ingress edge switch (i.e. connecting to AINI "X") of the ASP Network "W" assigns its own NCCI-W which is propagated to its egress edge switch (i.e. connecting to UNI "Y"). The NCCI-W is forwarded to the user side of the UNI "Y" via the SETUP message.
3. The ingress edge switch (i.e. connecting to UNI "Y") of the Private Network "T" recorded the NCCI-W and makes an association with its own NCCI-T which is used to replace the NCCI-W in the SETUP message. The NCCI-T is then propagated to the egress edge switch (i.e. connecting to UNI "B").
4. When the CONNECT message is returned, no NCCI is included in the message at UNI "B" and UNI "Y".
5. The ingress edge switch of the ASP Network "W" inserts the NCCI-W in the CONNECT message prior to progressing the CONNECT message to the user side of the AINI "X".
6. When the Private Network "S" receives the CONNECT message, it associates the NCCI-W with the NCCI-S.
7. By using the NCCI-W, the Private Network "S" and Private Network "T" can correlate the accounting records with their own NCCIs.